

## About this Manual

We've added this manual to the Agilent website in an effort to help you support your product. This manual is the best copy we could find; it may be incomplete or contain dated information. If we find a more recent copy in the future, we will add it to the Agilent website.

## Support for Your Product

Agilent no longer sells or supports this product. Our service centers may be able to perform calibration if no repair parts are needed, but no other support from Agilent is available. You will find any other available product information on the Agilent Test & Measurement website, [www.tm.agilent.com](http://www.tm.agilent.com).

## HP References in this Manual

This manual may contain references to HP or Hewlett-Packard. Please note that Hewlett-Packard's former test and measurement, semiconductor products and chemical analysis businesses are now part of Agilent Technologies. We have made no changes to this manual copy. In other documentation, to reduce potential confusion, the only change to product numbers and names has been in the company name prefix: where a product number/name was HP XXXX the current name/number is now Agilent XXXX. For example, model number HP8648A is now model number Agilent 8648A.

# **User's Guide**

## **HP 70875A Noise Figure Measurements Personality**



**HP Part No. 70875-90001  
Printed in USA May 1996**

**Edition A.0.0**

**Notice**

The information contained in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

**Restricted Rights Legend.**

Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 for DOD agencies, and subparagraphs (c) (1) and (c) (2) of the Commercial Computer Software Restricted Rights clause at FAR 52.227-19 for other agencies.

Lotus®1-2-3® is a U.S. registered trademark of Lotus Development Corporation.

MS-DOS® is a U.S. registered trademark of Microsoft Corporation.

Microsoft® is a U.S. registered trademark of Microsoft Corporation.

©Copyright Hewlett-Packard Company 1992, 1996

All Rights Reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.  
1400 Fountaingrove Parkway, Santa Rosa, CA 95403-1799, USA

---

# Hewlett-Packard Software Product License & Agreement and Limited Warranty

---

**Important** Please carefully read this License Agreement before opening the media envelope or operating the equipment. Rights in the software are offered only on the condition that the Customer agrees to all terms and conditions of the License Agreement. Opening the media envelope or operating the equipment indicates your acceptance of these terms and conditions. If you do not agree to the License Agreement, you may return the unopened package for a full refund.

---

---

## License Agreement

In return for payment of the applicable fee, Hewlett-Packard grants the Customer a license in the software, until terminated, subject to the following:

### Use

- Customer may use the software on one spectrum-analyzer instrument.
- Customer may not reverse assemble or decompile the software.

### Copies and Adaptations

- Customer may make copies or adaptations of the software:
  - For archival purposes, or
  - When copying or adaptation is an essential step in the use of the software with a computer so long as the copies and adaptations are used in no other manner.
- Customer has no other rights to copy unless they acquire an appropriate license to reproduce which is available from Hewlett-Packard for some software.
- Customer agrees that no warranty, free installation, or free training is provided by Hewlett-Packard for any copies or adaptations made by Customer.
- All copies and adaptations of the software must bear the copyright notice(s) contained in or on the original.

### Ownership

- Customer agrees that they do not have any title or ownership of the software, other than ownership of the physical media.
- Customer acknowledges and agrees that the software is copyrighted and protected under the copyright laws.
- Customer acknowledges and agrees that the software may have been developed by a third party software supplier named in the copyright notice(s) included with the software, who shall be authorized to hold the Customer responsible for any copyright infringement or violation of this License Agreement.

### Transfer of Rights in Software

- Customer may transfer rights in the software to a third party only as part of the transfer of all their rights and only if Customer obtains the prior agreement of the third party to be bound by the terms of this License Agreement.

- Upon such a transfer, Customer agrees that their rights in the software are terminated and that they will either destroy their copies and adaptations or deliver them to the third party.
- Transfer to a U.S. government department or agency or to a prime or lower tier contractor in connection with a U.S. government contract shall be made only upon their prior written agreement to terms required by Hewlett-Packard.

#### **Sublicensing and Distribution**

- Customer may not sublicense the software or distribute copies or adaptations of the software to the public in physical media or by telecommunication without the prior written consent of Hewlett-Packard.

#### **Termination**

- Hewlett-Packard may terminate this software license for failure to comply with any of these terms provided Hewlett-Packard has requested Customer to correct the failure and Customer has failed to do so within thirty (30) days of such notice.

#### **Updates and Upgrades**

- Customer agrees that the software does not include future updates and upgrades which may be available for HP under a separate support agreement.

#### **Export**

- Customer agrees not to export or re-export the software or any copy or adaptation in violation of the U.S. Export Administration regulations or other applicable regulations.

---

## **Limited Warranty**

### **Software**

Hewlett-Packard warrants for a period of 1 year from the date of purchase that the software product will execute its programming instructions when properly installed on the spectrum-analyzer instrument indicated on this package. Hewlett-Packard does not warrant that the operation of the software will be uninterrupted or error free. In the event that this software product fails to execute its programming instructions during the warranty period, customer's remedy shall be to return the measurement card ("media") to Hewlett-Packard for replacement. Should Hewlett-Packard be unable to replace the media within a reasonable amount of time, Customer's alternate remedy shall be a refund of the purchase price upon return of the product and all copies.

### **Media**

Hewlett-Packard warrants the media upon which this product is recorded to be free from defects in materials and workmanship under normal use for a period of 1 year from the date of purchase. In the event any media prove to be defective during the warranty period, Customer's remedy shall be to return the media to Hewlett-Packard for replacement. Should Hewlett-Packard be unable to replace the media within a reasonable amount of time, Customer's alternate remedy shall be a refund of the purchase price upon return of the product and all copies.

### **Notice of Warranty Claims**

Customer must notify Hewlett-Packard in writing of any warranty claim not later than thirty (30) days after the expiration of the warranty period.

### **Limitation of Warranty**

Hewlett-Packard makes no other express warranty, whether written or oral, with respect to this product. Any implied warranty of merchantability or fitness is limited to the 1 year duration of this written warranty.

This warranty gives specific legal rights, and Customer may also have other rights which vary from state to state, or province to province.

### **Exclusive Remedies**

The remedies provided above are Customer's sole and exclusive remedies. In no event shall Hewlett-Packard be liable for any direct, indirect, special, incidental, or consequential damages (including lost profit) whether based on warranty, contract, tort, or any other legal theory.

### **Warranty Service**

Warranty service may be obtained from the nearest Hewlett-Packard sales office or other location indicated in the owner's manual or service booklet.

---

## Safety Symbols

The following safety symbols are used throughout this manual. Familiarize yourself with each of the symbols and its meaning before operating this instrument.

---

**CAUTION**    The *caution* sign denotes a hazard. It calls attention to a procedure which, if not correctly performed or adhered to, could result in damage to or destruction of the instrument. Do not proceed beyond a *caution* sign until the indicated conditions are fully understood and met.

---

---

**WARNING**    The *warning* sign denotes a hazard. It calls attention to a procedure which, if not correctly performed or adhered to, could result in injury or loss of life. Do not proceed beyond a *warning* sign until the indicated conditions are fully understood and met.

---

---

## General Safety Considerations

---

**WARNING**    *Before the spectrum analyzer is switched on, make sure it has been properly grounded through the protective conductor of the ac power cable to a socket outlet provided with protective earth contact.*

**Any interruption of the protective (grounding) conductor, inside or outside the instrument, or disconnection of the protective earth terminal can result in personal injury.**

---

---

**CAUTION**    *Before the spectrum analyzer is switched on, make sure its primary power circuitry has been adapted to the voltage of the ac power source.*

Failure to set the ac power input to the correct voltage could cause damage to the instrument when the ac power cable is plugged in.

---

---

## **An Overview of This Measurement Solution**

This quick overview provides basic information about noise figure and gain measurement using the HP 70875A measurement solution.

Some main features of the noise figure measurements personality are listed below:

- User-friendly interface (includes configuration and measurement results displays).
- Storage and edit capability of multiple noise-source ENR data tables.
- Measurement marker functions.
- Multiple-point test-limit capability.
- Simultaneous display of swept noise figure and gain measurement results.
- Variable measurement bandwidth control.
- Mixer test compatibility (such as for frequency converters and receivers).
- Loss-compensation data entry to correct for cables and other losses.



---

## **In This Guide**

Read the following information to get an idea of what the different chapters of this guide contain.

- Chapter 1, “Getting Started” guides you through setting up the measurement personality (DLP) for use.
- Chapter 2, “Making Measurements” guides you through measurement examples. The recommended test equipment table, methods for optimizing measurement results, and measurement configuration information are located in this chapter. The default-configuration settings are listed here as well.
- Chapter 3, “Menu Key Descriptions” provides the menu diagrams for the DLP and a description of each menu key in alphabetical order.
- Chapter 4, “Specifications, Characteristics, and System Verification” provides the measurement specifications and characteristics along with a verification test.
- Chapter 5, “If you Have a Problem” includes descriptions of measurement error messages. Return-to-factory information is also included in this chapter.
- Chapter 6, “Programming” is the remote command reference. Commands and their descriptions are alphabetically listed in this chapter. A cross-reference table of the personality’s menu keys and their related commands are located in this chapter.

# Contents

---

## 1. Getting Started

Users' Guide Key Conventions . . . . .	1-1
Installing the Measurement Personality . . . . .	1-2
To dispose previously installed DLPs . . . . .	1-2
To load the noise figure and gain measurement DLP . . . . .	1-2
Verifying DLP Installation . . . . .	1-3

## 2. Making Measurements

Improving Noise Figure Measurement Accuracy . . . . .	2-2
Configuring for Measurements . . . . .	2-3
To use the default configuration . . . . .	2-3
To enter measurement frequencies . . . . .	2-3
To measure below 10 MHz . . . . .	2-3
To measure non-frequency converting devices . . . . .	2-3
To measure frequency converting devices . . . . .	2-3
To enter the number of measurements points . . . . .	2-4
To enter time-BW parameters . . . . .	2-5
To enter the measurement bandwidth . . . . .	2-5
To enter the averaging time . . . . .	2-5
To enter the time-bandwidth product . . . . .	2-6
To enter external losses . . . . .	2-6
To adjust RF attenuator . . . . .	2-11
To disable or enable internal preamp . . . . .	2-11
To enter noise-source case temperature . . . . .	2-11
To edit noise source ENR data . . . . .	2-12
To edit ENR data tables . . . . .	2-12
To save ENR data tables . . . . .	2-13
To recall ENR data tables . . . . .	2-13
Calibrating for Measurements . . . . .	2-15
Measuring Noise Figure and Gain of an Amplifier . . . . .	2-17
Configuring for the measurement . . . . .	2-17
Calibrate the measurement setup . . . . .	2-17
To measure the amplifier . . . . .	2-17
Measuring Amplifier Output ENR . . . . .	2-19
Configuring for the measurement . . . . .	2-19
Calibrate the measurement setup . . . . .	2-19
To measure the amplifier . . . . .	2-19
Measuring a Frequency Converter . . . . .	2-21
Configuring for the measurement . . . . .	2-21
Calibrate the measurement setup . . . . .	2-21
To measure a frequency converting device . . . . .	2-21
Double Sideband Converter Corrections . . . . .	2-23
Testing a Multiband Converter . . . . .	2-23
Adjusting the Results Display . . . . .	2-24
To adjust Reference Level . . . . .	2-24
To adjust Reference Level Position . . . . .	2-24

To adjust Amplitude Scale . . . . .	2-24
To use Display Markers . . . . .	2-25
To turn markers On or Off . . . . .	2-25
To use delta markers . . . . .	2-25
To move the marker to the highest or lowest amplitude . . . . .	2-25
To set the reference level equal to the marker amplitude . . . . .	2-25
To calculate a marker noise temperature . . . . .	2-25
To move the marker between the noise figure and gain traces . . . . .	2-26
Testing Results with Limit Lines . . . . .	2-27
To edit limit line data tables . . . . .	2-27
To save limit line tables . . . . .	2-28
To recall limit line tables . . . . .	2-28
To enable limit line testing . . . . .	2-29
Making Hard-Copies . . . . .	2-30
<b>3. Menu Key Descriptions</b>	
Menu Pages . . . . .	3-1
Menu Key Descriptions . . . . .	3-9
<b>4. Specifications, Characteristics, and Verification</b>	
Specifications and Characteristics . . . . .	4-2
System Performance Verification . . . . .	4-4
Verification Test Description . . . . .	4-4
Related Spectrum Analyzer Specifications . . . . .	4-4
Equipment required for the measurement . . . . .	4-4
Calibrate the Spectrum Analyzer . . . . .	4-5
Zero and Calibrate the Power Meter . . . . .	4-5
Calibrate For ENR Measurements . . . . .	4-5
Perform the Verification Test . . . . .	4-6
Interpreting the Verification Test Results . . . . .	4-7
If Verification Fails . . . . .	4-9
<b>5. If You Have a Problem</b>	
Measurement Personality Messages . . . . .	5-1
Returning the Instrument for Service . . . . .	5-6
<b>6. Programming</b>	
Reference Tables . . . . .	6-2
Functional Index Table . . . . .	6-2
Alphabetical Reference Table . . . . .	6-7
Command Syntax Description . . . . .	6-11
Command Reference . . . . .	6-12
_AVGTIME . . . . .	6-13
_AT . . . . .	6-14
_BEEP . . . . .	6-15
_BW . . . . .	6-16
_CAL . . . . .	6-18
_CONT . . . . .	6-19
_DEFAULTS . . . . .	6-20
_ENR . . . . .	6-22
_FCONV . . . . .	6-23
_FSTART . . . . .	6-24
_FSTOP . . . . .	6-25
_GAIN . . . . .	6-26
_HI . . . . .	6-27

_IFSTART . . . . .	6-28
_IFSTOP . . . . .	6-30
_INLOSS . . . . .	6-32
_LIMITEST . . . . .	6-34
_LG . . . . .	6-35
_LOW . . . . .	6-36
_MENR . . . . .	6-37
MK_RL . . . . .	6-38
_MKTEMP . . . . .	6-39
_MNF . . . . .	6-40
_MNFG . . . . .	6-41
_MSI . . . . .	6-42
_NF . . . . .	6-43
_NFMODE . . . . .	6-44
_NFSA . . . . .	6-45
_OUTLOSS . . . . .	6-46
_PLOTPTS . . . . .	6-48
_PREAMP . . . . .	6-49
_PTS . . . . .	6-50
_RCLENR . . . . .	6-51
_RCLLIM . . . . .	6-52
_REVNFG . . . . .	6-53
_RFSTART . . . . .	6-54
_RFSTOP . . . . .	6-56
_RL . . . . .	6-58
_RLPOS . . . . .	6-59
_SAVENR . . . . .	6-60
_SAVLIM . . . . .	6-61
_SLOSS . . . . .	6-62
_TBW . . . . .	6-64
_TBWAUTO . . . . .	6-65
_TEMPC . . . . .	6-66
Example Programs . . . . .	6-67
Creating and Saving Noise Source ENR Tables . . . . .	6-67
Creating and Saving Limit Line Tables . . . . .	6-68
Corrected Non-Conversion Noise Figure and Gain Measurements . . . . .	6-69
Frequency Conversion Measurement Mode . . . . .	6-71

**Index**

# Figures

---

1-1. Noise Figure Personality Main Menu . . . . .	1-3
2-1. System Loss Location During Calibration . . . . .	2-7
2-2. System Loss Location During Device Measurement . . . . .	2-7
2-3. SOURCE LOSS Location During Calibration . . . . .	2-8
2-4. SOURCE LOSS Location During Device Measurement . . . . .	2-8
2-5. INPUT LOSS Location During Calibration . . . . .	2-9
2-6. INPUT LOSS Location During Device Measurement . . . . .	2-9
2-7. OUTPUT LOSS Location During Calibration . . . . .	2-10
2-8. OUTPUT LOSS Location During Device Measurement . . . . .	2-10
2-9. The ENR Data Table Editor Screen . . . . .	2-12
2-10. Basic Calibration Setup . . . . .	2-15
2-11. Calibration Completion Display . . . . .	2-16
2-12. Measuring Amplifier Noise Figure and Gain . . . . .	2-17
2-13. Noise Figure and Gain Measurement of an Amplifier. Upper trace is gain, lower trace is noise figure. . . . .	2-18
2-14. Measuring Amplifier Output ENR . . . . .	2-19
2-15. Amplifier Output ENR Results Example . . . . .	2-20
2-16. Measuring a Frequency Converting Device . . . . .	2-22
2-17. Noise Figure and Gain Measurement of a Frequency Converter. Upper trace is gain, lower trace is noise figure. . . . .	2-23
2-18. The Limit Line Table Editor Screen . . . . .	2-27
3-1. The Frequency (non-converting) Menu Page . . . . .	3-2
3-2. The Frequency (converting) Menu Page . . . . .	3-2
3-3. The Amplitude Menu Page . . . . .	3-3
3-4. The Limit Lines Edit Menu Page . . . . .	3-3
3-5. The Marker Menu Page . . . . .	3-4
3-6. The Bandwidth & Averaging Menu Page . . . . .	3-4
3-7. The Measure Menu Page . . . . .	3-5
3-8. The State Menu Page 1 . . . . .	3-5
3-9. The Recall Menu Page . . . . .	3-6
3-10. The Save Menu Page . . . . .	3-6
3-11. The Edit ENR Source Menu Page . . . . .	3-7
3-12. The Verify Specs Menu Page . . . . .	3-7
3-13. The State Menu Page 2 . . . . .	3-8
4-1. Calibration Setup for ENR Measurements . . . . .	4-5
4-2. Verification Test Setup . . . . .	4-7
4-3. Example Verification Test Result . . . . .	4-8
6-1. Syntax Structure Description . . . . .	6-11
6-2. _AVGTIME Syntax . . . . .	6-13
6-3. _AVGTIME Query Response Syntax . . . . .	6-13
6-4. _AT Syntax . . . . .	6-14
6-5. _AT Query Response Syntax . . . . .	6-14
6-6. _BEEP Syntax . . . . .	6-15
6-7. _BEEP Query Response Syntax . . . . .	6-15

6-8.	_BW Syntax . . . . .	6-16
6-9.	_BW Query Response Syntax . . . . .	6-17
6-10.	_CAL Syntax . . . . .	6-18
6-11.	_CONT Syntax . . . . .	6-19
6-12.	_CONT Query Response Syntax . . . . .	6-19
6-13.	_DEFAULTS Syntax . . . . .	6-20
6-14.	_ENR Syntax . . . . .	6-22
6-15.	_ENR Query Response Syntax . . . . .	6-22
6-16.	_FCONV Syntax . . . . .	6-23
6-17.	_FCONV Query Response Syntax . . . . .	6-23
6-18.	_FSTART Syntax . . . . .	6-24
6-19.	_FSTART Query Response Syntax . . . . .	6-24
6-20.	_FSTOP Syntax . . . . .	6-25
6-21.	_FSTOP Query Response Syntax . . . . .	6-25
6-22.	_GAIN Syntax . . . . .	6-26
6-23.	_GAIN Query Response Syntax . . . . .	6-26
6-24.	_HI Syntax . . . . .	6-27
6-25.	_HI Query Response Syntax . . . . .	6-27
6-26.	_IFSTART Syntax . . . . .	6-28
6-27.	_IFSTART Query Response Syntax . . . . .	6-29
6-28.	_IFSTOP Syntax . . . . .	6-30
6-29.	_IFSTOP Query Response Syntax . . . . .	6-31
6-30.	_INLOSS Syntax . . . . .	6-32
6-31.	Location of Input Loss Characteristic . . . . .	6-33
6-32.	_INLOSS Query Response Syntax . . . . .	6-33
6-33.	_LIMITEST Syntax . . . . .	6-34
6-34.	_LIMITEST Query Response Syntax . . . . .	6-34
6-35.	_LG Syntax . . . . .	6-35
6-36.	_LG Query Response Syntax . . . . .	6-35
6-37.	_LOW Syntax . . . . .	6-36
6-38.	_LOW Query Response Syntax . . . . .	6-36
6-39.	_MENR Syntax . . . . .	6-37
6-40.	MK_RL Syntax . . . . .	6-38
6-41.	_MKTEMP Syntax . . . . .	6-39
6-42.	_MKTEMP Query Response Syntax . . . . .	6-39
6-43.	_MNF Syntax . . . . .	6-40
6-44.	_MNFG Syntax . . . . .	6-41
6-45.	_MSI Syntax . . . . .	6-42
6-46.	_MSI Query Response Syntax . . . . .	6-42
6-47.	_NF Syntax . . . . .	6-43
6-48.	_NF Query Response Syntax . . . . .	6-43
6-49.	_NFMODE Syntax . . . . .	6-44
6-50.	_NFMODE Query Response Syntax . . . . .	6-44
6-51.	_NFSA Syntax . . . . .	6-45
6-52.	_NFSA Query Response Syntax . . . . .	6-45
6-53.	_OUTLOSS Syntax . . . . .	6-46
6-54.	Location of Output Loss Characteristic . . . . .	6-47
6-55.	_OUTLOSS Query Response Syntax . . . . .	6-47
6-56.	_PLOTPTS Syntax . . . . .	6-48
6-57.	_PLOTPTS Query Response Syntax . . . . .	6-48
6-58.	_PREAMP Syntax . . . . .	6-49
6-59.	_PREAMP Query Response Syntax . . . . .	6-49
6-60.	_PTS Syntax . . . . .	6-50
6-61.	_PTS Query Response Syntax . . . . .	6-50
6-62.	_RCLENR Syntax . . . . .	6-51

6-63.	_RCLENR Query Response Syntax . . . . .	6-51
6-64.	_RCLLIM Syntax . . . . .	6-52
6-65.	_RCLLIM Query Response Syntax . . . . .	6-52
6-66.	_REVNFG Syntax . . . . .	6-53
6-67.	_REVNFG Query Response Syntax . . . . .	6-53
6-68.	_RFSTART Syntax . . . . .	6-54
6-69.	_RFSTART Query Response Syntax . . . . .	6-55
6-70.	_RFSTOP Syntax . . . . .	6-56
6-71.	_RFSTOP Query Response Syntax . . . . .	6-57
6-72.	_RL Syntax . . . . .	6-58
6-73.	_RL Query Response Syntax . . . . .	6-58
6-74.	_RLPOS Syntax . . . . .	6-59
6-75.	_RLPOS Query Response Syntax . . . . .	6-59
6-76.	_SAVENR Syntax . . . . .	6-60
6-77.	_SAVENR Query Response Syntax . . . . .	6-60
6-78.	_SAVLIM Syntax . . . . .	6-61
6-79.	_SAVLIM Query Response Syntax . . . . .	6-61
6-80.	_SLOSS Syntax . . . . .	6-62
6-81.	Location of Noise Source Loss Characteristic . . . . .	6-62
6-82.	_SLOSS Query Response Syntax . . . . .	6-63
6-83.	_TBW Syntax . . . . .	6-64
6-84.	_TBW Query Response Syntax . . . . .	6-64
6-85.	_TBWAUTO Syntax . . . . .	6-65
6-86.	_TBWAUTO Query Response Syntax . . . . .	6-65
6-87.	_TEMPC Syntax . . . . .	6-66
6-88.	_TEMPC Query Response Syntax . . . . .	6-66

# Tables

---

2-1. Equipment Requirements . . . . .	2-1
2-2. Points Entered vs Points Measured . . . . .	2-4
3-1. Noise Figure Personality Default Parameters . . . . .	3-10
3-2. Verification Test Default Parameters . . . . .	3-11
4-1. Specifications . . . . .	4-3
5-1. Measurement Personality Error Messages . . . . .	5-2
5-2. Measurement Personality Information Messages . . . . .	5-3
6-1. Functional Index . . . . .	6-2
6-2. Commands in Alphabetical Order . . . . .	6-7





## Getting Started

---

The noise figure and gain measurements require an HP 70000 Series spectrum analyzer. The information about measurements in this guide assume you are using an HP 70620B preamplifier module and an HP 346B/C noise source.

The sections in this chapter provide the following:

- Instructions for installing the HP 70875A Noise Figure Measurements Personality into an HP 70000 series spectrum analyzer
- Instructions for verifying that the personality was installed correctly

---

### Users' Guide Key Conventions

The following key conventions are used throughout this guide:

<b>FRONT PANEL KEY</b>	Boxed text indicates a key physically located on the front-panel of the MMS display.
<b>Softkey</b> and <b>SOFTKEY</b>	Shaded text indicates a key label that appears on the display of the spectrum analyzer. The keys that are associated with the labels are physically located on the left- and right-hand sides of the spectrum analyzer display. These are frequently referred to in text as the measurement personality's menu keys.
Screen Text	Bold text in this typeface indicates information that you may see displayed on the spectrum analyzer screen. This is often representative of prompts, warnings, and results information.
<b>Note</b>	When pressing hardkeys or softkeys, be sure to allow sufficient time for the spectrum analyzer to respond to the command. Fast, consecutive key presses may cause an error in the spectrum analyzer.

---

---

## Installing the Measurement Personality

To install the noise figure and gain measurement personality, all of the spectrum analyzer user memory needs to be available. Dispose previously installed DLPs, then install the HP 70875A DLP.

### To dispose previously installed DLPs

The measurement program requires some of the user memory in the spectrum analyzer. Refer to the steps below to dispose previously installed user programs:

1. Press **(INSTR PRESET)** on the spectrum analyzer.
2. Erase the current user programs (DLPs) and analyzer calibration from user memory.

Press the front panel **(MENU)** key. Then press the softkeys **Misc**, **MORE**, **service**, **erase/restart**, **ERASE ALL**, **CONFIRM ERASE**. The analyzer will then erase internal memory and all instrument settings. When the MEASURE light on the HP 70900B front panel begins to blink, the memory erase is complete. To return analyzer control to the display, press **(DISPLAY)**, **NEXT INSTR**.

### To load the noise figure and gain measurement DLP

After the memory is cleared, insert the HP 70875A measurement personality card into the display's front panel card reader slot. Match the card's arrow with the arrow printed above the card slot.

To load the noise figure and gain DLP, refer to the following steps:

1. Press the front-panel **(MENU)** key.
2. Press the softkeys **Misc**, **MORE**, **catalog & MSI**, **HP-MSIB CARD**. The display will show the contents of the memory card. If the message 2053 Storage device error appears, the wrong MSIB column address for the 70004A display may be selected. To fix this, press the front panel numeric key(s) for the correct display MSIB column number, then press **ENTER**. The 2053 error message can also be caused by having the HP 70004A display selecting the wrong mass storage unit. To correct this, press **(DISPLAY)**, **Mass Storage**, **msi**, **Memory Card**.
3. The file labeled HP70875A is the Noise Figure Measurements DLP. To load it into internal memory, press the **LOAD FILE** softkey, enter the file number from the display, then press **ENTER**. Wait about 40 seconds while the LED next to the card reader slot on the HP 70004A display is flashing.
4. Press the **(USER)** front panel key. The soft key in the upper right-hand corner of the display should read **NF\_GAIN DLP**. This indicates that the noise figure measurements personality has been loaded into internal memory.

## Verifying DLP Installation

To verify that the noise figure measurement personality has been correctly loaded into internal memory, use the following procedure:

1. Press **(INSTR PRESET)** on the spectrum analyzer.
2. If the **UNCOR** warning appears on the display, the spectrum should be calibrated. To do this, connect the Calibrator output on the HP 70900B module to the RF Input on the preamplifier module. Then press **(MENU)**, **Amptd**, **CAL ALL**. The calibration routine runs several minutes, depending on the module configuration. The routine ends when the End of Calibration message appears on the display.
3. Press the **(USER)** front panel key, then press the **NF\_GAIN DLP** softkey. When the DLP completes its initialization, the noise figure measurements personality top level menu will appear on the display as shown in Figure 1-1.
4. To return to the normal spectrum analyzer mode, press the **EXIT NF** softkey.




Figure 1-1. Noise Figure Personality Main Menu



## Making Measurements

---

This chapter contains instructions for using the measurement personality. The descriptions of the menu keys are located in Chapter 3, “Menu Key Descriptions.”

“Making Measurements” is organized into the following sections:

- Improving Noise Figure Measurement Accuracy
- Configuring for Measurements
  - Using the default configuration
  - Entering measurement frequencies
  - Entering points to be measured
  - Entering time and BW parameters
  - Entering external losses
  - Adjusting the RF attenuator
  - Enabling or disabling the internal preamp
  - Entering noise source case temperature
  - Editing noise source ENR data
- Calibrating for Measurements
- Making Noise Figure and Gain Measurements on an Amplifier
- Making Output ENR Measurements on an Amplifier
- Making Measurements on a Frequency Converter
- Adjusting the Results Display
- Using Display Markers
- Testing Results with Limit Lines
- Making Hard Copies

The measurement examples provided here use the equipment listed in Table 2-1 on the following page. Other equipment can be substituted if the critical specifications are accommodated.

**Table 2-1. Equipment Requirements**

Instrument	Model Number	Specifications
HP 70000 Series Spectrum Analyzer	HP 71100C, HP 71209A, HP 71210C, or HP 71910A	70900B firmware rev 940120 or later
Noise Source	HP 346B/C Noise Source	Frequency range: 10 MHz to 26.5 GHz ENR: 12 to 17 dB 10 MHz to 18 GHz, SWR: 1.25 18 MHz to 26.5 GHz, SWR: 1.35 Power requirement: 28 Vdc ( $\pm 1$ Vdc)
System Preamplifier	HP 70620B Opt.001 Preamplifier Module	Frequency Range: 100 KHz to 26.5 GHz Noise Figure: 16 dB to 26.5 GHz Input SWR: 3:1 (maximum)

---

## Improving Noise Figure Measurement Accuracy

You can improve the accuracy of a noise figure measurement by following the suggestions listed below:

- Use RF precautions with the equipment setup. Some of these are listed below:
  - Tighten measurement connections and avoid using non-threaded connectors such as the BNC-style connectors.
  - Use only cables that are in good condition.
  - Make measurements away from potentially interfering signals.
- “Increase” device gain, if possible.
  - Higher device gain minimizes many errors related to the measurement system.
- Reduce known error sources such as SWR and ENR uncertainty.
- Use a narrower measurement bandwidth than the bandwidth of the device under test.

---

## Configuring for Measurements

Before a measurement can be made, measurement parameters and states need to be set, if they are to be changed from default states. The following pages show how to configure the measurement by entering parameters.

It is assumed that the analyzer is already operating in the noise figure measurement mode. For information on invoking the noise figure measurement mode, refer to Chapter 1, “Verifying DLP Installation”.

### To use the default configuration

The noise figure personality has a default configuration. By invoking the default configuration, you will have a known state from which to make further modifications. Refer to the following steps:

1. Press **State** in the main (left-hand) menu.
2. Press **DEFAULT STATE** in the right-hand menu to set up the default configuration. The message `\Default State Restored\` appears on the display.

---

**Note** When you exit the noise figure measurement mode and return to normal spectrum analyzer operation, the noise figure configuration is stored by the DLP. When the noise figure mode is again invoked, the original noise figure configuration is restored.

---

### To enter measurement frequencies

The frequency range of the noise figure measurement setup is 10 MHz to the maximum input frequency of the RF section used in the spectrum analyzer. You can easily measure a device whose output frequency range falls within this span without additional hardware.

#### To measure below 10 MHz

To measure a device having a frequency range below the 10 MHz specification of the HP 70875A measurement personality, you need to provide a low-frequency system preamplifier (such as the HP 8447) and a low frequency calibrated noise source. Also, the specifications in Table 4-1 may not apply when other than an HP 70620B preamplifier is used.

#### To measure non-frequency converting devices

To enter the RF frequency range of the non-frequency converting device under test, refer to the following steps:

1. Press **Freq** in the main (left-hand) menu.
2. Press **FrqConv YES NO** to underline NO (the default setting) when you are measuring a device other than a frequency converter.
3. Press **START FREQ** and **STOP FREQ** to enter the start and stop frequencies of the DUT.

#### To measure frequency converting devices

The measurement personality frequency menu supports two modes. The first mode described above is for non-frequency converting devices. The second mode is for frequency converting devices.



When the DUT (device-under-test) is a frequency converter, the RF and IF frequency values need to be entered. The RF frequency values are used in the personality to select the appropriate ENR data. The IF frequencies are those of the DUT output.

To set the measurement frequency range for frequency converters, refer to the following steps:

1. Press **Freq** in the main (left-hand) menu.
2. Press **FrqConv YES NO** to underline YES when you are measuring a frequency conversion device.
3. Enter the IF and RF start and stop frequencies of the DUT.

---

**Note** Be sure to enter an RF frequency span equal to the IF frequency span. The RF span must equal the IF span even if it results in a “backwards” sweep condition.

---

- Press **RF STRT FREQ** and **RF STOP FREQ** to enter the RF frequency values of the DUT.
- Press **IF STRT FREQ** and **IF STOP FREQ** to enter the IF frequency values of the DUT.

### To enter the number of measurements points

Enter the number of measurement points you want to use. The larger the number of points, the longer the measurement. As few as 1 point or as many as 800 points can be measured, as listed in Table 2-2 below. You can modify the speed of measurements via the time-BW menu keys.

To enter the number of measurement points, refer to the following steps:

1. Press **Freq** in the main (left-hand) menu.
2. Press **POINTS** in the right-hand menu.
3. Enter the number of points, from 1 to 800, you want to measure.
4. Press the front-panel ENTER key to complete data entry.

If you choose to enter one point, the measurement will be made at the Start Frequency for non-conversion mode or the RF Start Frequency for conversion mode. For a single-point measurement, the results display will be text. For a multi-point measurement, the results display will be a graph.

**Table 2-2. Points Entered vs Points Measured**

Number Entered	Actual Number of Points Measured
1	1 point
2	1 point
$3 \leq N \leq 800$	N points
$800 < N$	800 points

## To enter time-BW parameters

Enter time-bandwidth measurement parameters via the **BW, Avg** main menu key.

### To enter the measurement bandwidth

To set the measurement bandwidth, use the following steps:

1. Press **BW, Avg** in the main (left-hand) menu.
2. Press **RES BW** and use the front-panel data keys, enter a measurement bandwidth.
  - Use 3 MHz measurement bandwidth, except when measuring narrow band devices.
  - For narrow band devices, use a bandwidth narrower than the device bandwidth.
3. Terminate data entry by pressing a frequency units key.

### To enter the averaging time

To set the averaging time, use the following steps:

1. Press **BW, Avg** in the main (left-hand) menu.
2. Press **AVG TIME** and use the front-panel data keys, enter an averaging time value.
  - Enter a larger value to reduce repeatability error (jitter), but increase measurement time.
  - Enter a smaller value to reduce measurement time, at the cost of increased measurement repeatability error (jitter).
3. Terminate data entry by pressing a time units key.

## To enter the time-bandwidth product

There is an inverse, square-root proportionality between repeatability and the time-BW factor. By doubling the time-bandwidth product in a noise figure measurement, the measurement repeatability can be increased by a factor of the square root of two. By setting the averaging time to AUTO, the averaging time will be automatically adjusted so that the time-bandwidth product is a constant. To set the time-bandwidth product in MHz-seconds, multiply the desired averaging time in seconds by the measurement bandwidth in MHz. Increasing the time-bandwidth value can reduce the measurement's repeatability error. The following steps guide you through data entry.

1. Press **T\*BW PRODUCT** key.
  - Enter a larger value to reduce repeatability error (jitter), but increase measurement time.
  - Enter a smaller value to reduce measurement time, at the cost of increased measurement repeatability error (jitter).
2. Press **AVGTIME AutoMan** to underline Auto, so that the averaging time is automatically calculated to keep the time-bandwidth product constant.

## To enter external losses

If you plan to use hardware or cables that have known losses, you can enter these values into the measurement configuration settings. When you are correcting for external losses, accurate loss values should be used to prevent introducing errors into the device measurements.

---

**Note** Note that only positive dB values can be entered as external losses.

---

There are four points that can contribute loss into the measurement. One of the four points is the test system loss.

Do not enter corrections for the loss encountered at the point labeled "System Loss" shown in Figure 2-1 and Figure 2-2. System loss is automatically factored into the final measurement result.


To enter corrections for the remaining three loss locations, refer to the information below:

1. Press the **State** main (left-hand) menu softkey.
2. Press the **Ext Losses** right-hand softkey. Enter known loss values designated as:

**SOURCE LOSS**


**INPUT LOSS**

**OUTPUT LOSS**



pa713a


**Figure 2-1. System Loss Location During Calibration**



pa77a


**Figure 2-2. System Loss Location During Device Measurement**

- Press **SOURCE LOSS** and enter the known loss value present at the location indicated in Figure 2-4 or Figure 2-3. The loss is subtracted from the noise source excess noise ratio (ENR).



pa714a


**Figure 2-3. SOURCE LOSS Location During Calibration**



pa78a


**Figure 2-4. SOURCE LOSS Location During Device Measurement**

- Press **INPUT LOSS** and enter the known loss value present at the location indicated in Figure 2-5 or Figure 2-6 as the input loss. The input loss of the DUT is added to its noise figure, but subtracted from its gain.



pa715a


**Figure 2-5. INPUT LOSS Location During Calibration**



pa79a


**Figure 2-6. INPUT LOSS Location During Device Measurement**

- Press **OUTPUT LOSS** and enter the known loss value present at the location indicated in Figure 2-7 or Figure 2-8 as the output loss. The output loss is subtracted from the gain or the device under test, but proportionally calculated into its noise figure.



pa716a

Figure 2-7. **OUTPUT LOSS** Location During Calibration



pa710a

Figure 2-8. **OUTPUT LOSS** Location During Device Measurement

## To adjust RF attenuator

The input attenuator in the RF section can be adjusted with the noise figure measurements personality. When the preamp is enabled, an attenuation value of 0 will generally provide the best system noise figure. However, high gain devices can have high levels of output noise power which can overload the preamp and cause measurement inaccuracy. In this case, the preamp can be disabled and the input attenuator should be set to prevent overloading of the input mixer in the RF section. To set the RF attenuator, refer to the following steps:

1. Press **Amptd** in the main (left-hand) menu.
2. Press **ATTEN** in the right-hand menu. Use the front-panel data keys to enter the exact values, then complete the data entry by pressing the **dB** units key.

---

**Note** In using the **ATTEN** softkey, values can be entered that do not correspond to actual attenuator hardware capability. Refer to the spectrum analyzer operation manual to determine valid attenuator range and step size. Check the annotation in the upper left-hand corner of the display for the actual RF attenuator state.

---

## To disable or enable internal preamp

The internal MMS preamp (HP 70621A, HP 70620A or HP 70620B module) can be enabled or disabled (amplifier bypassed). Bypassing the preamp is useful in testing high gain devices whose output noise would overload the internal preamp. In this case, noise figure calibration may not work well due to the relatively high noise figure of the spectrum analyzer, but an uncorrected noise figure measurement could still be made (uncorrected noise figure measurements do not require a cal). Refer to the following steps:

1. Press **State** in the main (left-hand) menu.
2. Press **MORE 1 of 2** in the right-hand menu.
3. Press **INT AMP OnOff** to underline “Off” to disable the internal preamp, or “On” to enable the internal preamp.

## To enter noise-source case temperature

The noise-source case temperature, or ambient temperature, contributes to measurement accuracy results. If the noise source is used to measure devices within a temperature chamber, the temperature of the chamber needs to be entered into the configuration settings. Refer to the following steps:

1. Press **State** in the main (left-hand) menu.
2. Press **MORE 1 of 2** in the right-hand menu.
3. Press **SOURCE TEMP** and enter the ambient temperature of the testing environment. Retain the default setting of 17°C for measurements made in typical room-temperature environments.
  - Use the **↑** and **↓** keys to change the temperature value in 1.0°C increments. Do not press ENTER. The value is automatically accepted.



- Either do not use the RPG knob or use it very carefully. The RPG knob will change the temperature value very fast. Small rotations cause large changes. Do not press ENTER; the value is automatically accepted.
- Use the front-panel data keys to enter exact values, then press ENTER.

### To edit noise source ENR data

The noise source's ENR (excess noise ratio) data is used by the personality to calculate measurement results. The data listed on the noise source is typically unique to each noise source. ENR data tables can be saved to, or recalled from memory cards and spectrum analyzer internal files.

**Note** The measurement personality arrives with a default ENR-data table installed in memory. Either the default table, or the table that was last edited, saved, or recalled, is the table that is used. The ENR data is used by the personality in calculating corrected results.

### To edit ENR data tables

Press **State**, then **EditSrc ENR**. The currently active ENR table data is displayed. Refer to Figure 2-9 for an example of an ENR table.

hp 14:33:54 APR 17, 1996  
 RL 0.00 dBm MKR #1 FRQ 150 MHz  
 \*ATTEN 0 dB 0.00 dBm  
 2.00 dB/DIV SAMPLE \*  
 Freq  
 Amptd  
 Marker  
 BW, Avg  
 Measure  
 State  
 EXIT \*START 100 MHz STOP 205 MHz EDIT  
 NF \*RB 3.00 MHz VB 3.00 MHz \*ST 6.300 sec DONE

Seq	Fixed Freq	Upper Amptd	Type	
1	10.0 MHz	19.00 dBm	SLOPE	NEXT POINT
2	100 MHz	19.00 dBm	SLOPE	
3	1.000 GHz	19.00 dBm	SLOPE	
4	2.000 GHz	19.00 dBm	SLOPE	LAST POINT
5	3.000 GHz	19.00 dBm	SLOPE	
6	4.000 GHz	19.00 dBm	SLOPE	
7	5.000 GHz	19.00 dBm	SLOPE	DELETE POINT
8	6.000 GHz	19.00 dBm	SLOPE	
9	7.000 GHz	19.00 dBm	SLOPE	
10	8.000 GHz	19.00 dBm	SLOPE	
11	9.000 GHz	19.00 dBm	SLOPE	

Figure 2-9. The ENR Data Table Editor Screen

To enter the ENR data specific to the noise source you are using, refer to the following steps:

1. Press **FREQ VALUE**, **AMPTD VALUE**, **NEXT POINT**, or **LAST POINT** to move the entry window to a new or existing ENR-data point.
2. Change the table values as explained below:

- Change the frequency value using the front-panel data keys and terminate the entry with the frequency units softkey.
- Change the amplitude value using the front-panel data keys and terminate the entry with the dBm units softkey.

---

**Note** Use the dBm units key for entering amplitude, even though the noise source label uses dB as the units of ENR

---

- Press the **DELETE POINT** key to delete all the values of a point from the table, regardless of the highlighting position in a data point.
  - Press **Edit Done** to return to the previous menu. The edited ENR data is used for the next measurements.
3. To store the ENR data table to a memory file, use the **SAVE ENR** softkey as explained in the following section.

### To save ENR data tables

To save the ENR data to a memory file, press **EDIT DONE**, then follow the steps below:

1. Press the **State** main (left-hand) menu softkey. Then press the **save** right-hand softkey.
2. Press **MSI IntCard** to underline the save destination you want to use. “Int” chooses the spectrum analyzer internal memory files. “Card” selects the MSIB memory card reader on the front panel of the HP 70004A display.
3. Press **SAVE ENR**, then enter the memory register number you wish to use, then press **ENTER** on the front panel.

---

**Note** External card files and internal files 1 to 4999 are available. Be aware that ENR data is stored as limit line files (L\_1 to L\_4999) in either internal or external (card) memory. To help keep track of ENR files, it is recommended to use the last four digits of the noise source serial number for the file storage number.

---

**WARNING** When storing limit line files during normal spectrum analyzer operation, be careful not to write over existing ENR tables. The ENR table used in measurements is stored in the L\_0 limit line file in internal memory.

---

### To recall ENR data tables

ENR data tables may be recalled from spectrum analyzer memory, or from a memory card file. To recall existing ENR data tables, refer to the steps below:

1. Press the **State** main (left-hand) menu softkey. Then press the **recall** right-hand softkey.
2. Press **MSI IntCard** to underline the recall memory you want to use. “Int” chooses the spectrum analyzer internal memory files. “Card” selects the MSIB memory card reader on the front panel of the HP 70004A display.
3. Press **RECALL ENR**, then enter the file number you wish to use, then press **ENTER**.

---

**Note** ENR data tables are prefixed “1\_” in spectrum analyzer memory or in memory card memory.

---

To verify the recall of the ENR data, use the table editing technique described earlier in this section.

---

## Calibrating for Measurements

The calibration procedure minimizes the effects of losses, noise, and gain factors due strictly to the measurement setup. It must be performed prior to corrected Noise Figure and Gain measurements or ENR measurements.

After entering the measurement configuration information, calibrate the measurement setup. The calibration data is stored and available for the current measurement configuration.

If you cycle power, the configuration information is not changed, however, a new calibration is recommended before you resume measuring, especially if the instrument temperature has changed.


Calibration requires the following:

- The device to be tested is *not* connected.
- The measurement configurations are determined.
- The noise source is connected.

---

**Note** You can make noise figure measurements without completing calibration. However, the gain measurement will not be made (no gain trace displayed). An additional “second stage” error occurs in the measurement results when calibration is bypassed. The error is especially noticeable when low gain devices-under-test are measured.

---



pa72a

**Figure 2-10. Basic Calibration Setup**

For calibration, refer to the steps below:


1. Connect the test equipment as illustrated in Figure 2-10. Be sure to include your specific connectors, cables and adapters required for making your measurement.
2. Press the **Measure** main (left-hand) softkey, then press the **CAL** right-hand softkey. The message \Connect NS to SA INPUT, Press CAL\ appears on the display. Press the **CAL** softkey again to start the calibration routine.
3. Refer to Figure 2-11 for an example of the message displayed when calibration is completed.

4. Connect the device to test and begin making measurements. Some examples are included in this chapter.

---

**Note** Changing the RFstart, and RFstop (for frequency converter measurements) after calibration does not require measurement recalibration. However, changing other measurement configuration parameters will require recalibration before corrected measurements can be made.

---



**Figure 2-11. Calibration Completion Display**

---

## Measuring Noise Figure and Gain of an Amplifier

To measure the noise figure and gain of an amplifier, use the following procedure.

### Configuring for the measurement

Refer to the “Configuring for Measurements” pages for information on configuring the noise figure measurement. Use the frequency values that are unique to the device you are testing. Be sure to underline **No** in the **FrqConv Yes No** key.

### Calibrate the measurement setup

To calibrate the measurement setup, include all the hardware and cabling required for your measurement, unless you have entered DUT input and/or output losses. Use the procedure listed in “Calibrating for Measurements” to calibrate the measurement setup. At the end of the measurement, a message appears to indicate calibration completion.


### To measure the amplifier

To measure an amplifier, connect the equipment as indicated in Figure 2-12. Press the **Measure** main softkey. For a corrected noise figure and gain measurement, press **MEASURE NF&GAIN** twice. If you do not calibrate, press **MEASURE NF** two times to begin an uncorrected noise figure measurement. Refer to Figure 2-13 for an example of the measurement results. The noise figure is in Trace A, and the gain is in Trace B.


---

**Note**                      Uncorrected noise figure measurements can be made, however, there will be no gain measurement trace.

---



**Figure 2-12. Measuring Amplifier Noise Figure and Gain**



**Figure 2-13.**  
**Noise Figure and Gain Measurement of an Amplifier.**  
**Upper trace is gain, lower trace is noise figure.**

---

## Measuring Amplifier Output ENR

The HP 70875A Noise Figure Measurements Personality can also measure the output excess noise ratio of a device. This is useful in characterizing devices which have very high noise figures. It can also be used to compare a noise source to a known reference noise source. To measure the output ENR of an amplifier, use the following procedure.

### Configuring for the measurement

Refer to the “Configuring for Measurements” pages for information on configuring the noise figure measurement. Use the frequency values that are unique to the device you are testing.

---

**Note** Be sure to underline **No** in the **FrqConv Yes No** key. An output ENR measurement can only be made in the frequency non-conversion mode.

---

### Calibrate the measurement setup

To calibrate the measurement setup, include all the hardware and cabling required for your measurement, unless you have entered DUT output losses. Use the procedure listed in “Calibrating for Measurements” to calibrate the measurement setup. At the end of the measurement, a message appears to indicate calibration completion.

### To measure the amplifier

To measure an amplifier, connect the equipment as indicated in Figure 2-14. Press the **Measure** main softkey. For an output ENR measurement, press **MEASURE ENR** twice. Refer to Figure 2-15 for an example of the measurement results.

---

**Note** An output ENR measurement cannot be made unless a calibration has been previously performed. If configuration parameters are changed, a calibration must be made before an output ENR measurement can be made.

---




Figure 2-14. Measuring Amplifier Output ENR






Figure 2-15. Amplifier Output ENR Results Example

---

## Measuring a Frequency Converter

To measure the noise figure and gain of a frequency converting device such as a mixer, use the following procedure.

### Configuring for the measurement

Refer to the “Configuring for Measurements” pages for information on configuring the noise figure measurement. Refer to the steps below to enter measurement parameters for the frequency converter. The specific values are not included. Use the values unique to the device you are testing.

- Be sure to underline **Yes** in the **FrqConv Yes No** key.
- Enter the RF and IF frequencies of the device you are testing. *The RF and IF spans must be equal.*
- The IF start frequency must correspond with the RF start frequency, even if the resulting values cause a “backwards sweep” condition (IF start frequency is greater than the IF stop frequency).

### Calibrate the measurement setup

To calibrate the measurement setup, include all the hardware and cabling required for your measurement, unless you have entered DUT input and/or output losses. Use the procedure listed in “Calibrating for Measurements” to calibrate the measurement setup. At the end of the measurement, a message appears to indicate calibration completion.


### To measure a frequency converting device

Press the **Measure** main softkey. To measure the noise figure and gain of a frequency converter, connect the equipment as indicated in Figure 2-16, then press **MEASURE NF&GAIN** twice. If you do not calibrate, press **MEASURE NF** two times to begin measurements. Refer to Figure 2-17 for an example of the measurement results. The noise figure is in Trace A, and the gain is in Trace B.

---


**Note**                      Uncalibrated noise figure measurements can be made, however, there will be no gain measurement trace.

---



pa73a

**Figure 2-16. Measuring a Frequency Converting Device**



**Figure 2-17.**  
**Noise Figure and Gain Measurement of a Frequency Converter.**  
 Upper trace is gain, lower trace is noise figure.

### Double Sideband Converter Corrections

**Note** To correct for the effect of double sideband mixing, enter an additional  $-3$  dB with the **INPUT LOSS** correction value. The actual resulting value is a sum of the loss correction of the converter input with the  $-3$  dB algebraically added, as shown below:

For input loss = 0, + additional  $-3$  dB,  
 equals:  $-3$  dB

For input loss = 5, + additional  $-3$  dB, equals: 2 dB

### Testing a Multiband Converter

**Note** This measurement personality allows you to test a device such as a multiband-frequency converter at several RF input frequencies. If you keep the IF output frequency fixed, you can adjust the RF input frequency, and continue measurements *without* having to recalibrate the measurement configuration.

For frequency-conversion measurements, the RF frequency values entered in the configuration menu are used only to determine which ENR data to use. The ENR of quality noise sources is very constant over frequency, therefore, the exact RF value need not be entered, in most cases.

---

## Adjusting the Results Display

For multi-point measurements (number of frequency points >1), the results display is a graph. The amplitude scale can be adjusted for better viewing with softkey functions found under the **Amptd** main (left-hand) menu:

### To adjust Reference Level

To adjust the display reference level, press the **REF LVL** left-hand softkey and use one of the following methods:

- Use the **↑** and **↓** keys to change the reference level in 1 division increments.
- Use the front-panel data keys to enter exact values. Terminate data-key entry with the **dBm** key.
- Use the RPG knob to change the value in small dB increments.

### To adjust Reference Level Position

To adjust the display reference level position, press the **REF LVL POSN** left-hand softkey and use one of the following methods:

- Use the **↑** and **↓** keys to change the reference level position in 1 division increments.
- Use the front-panel data keys to enter exact values. Terminate data-key entry with the **ENTER** key.
- Use the RPG knob to change the value in one division increments.

### To adjust Amplitude Scale

To adjust the display amplitude scale, press the **LOG dB/DIV** right-hand softkey and use one of the following methods:

- Use the **↑** and **↓** keys to change the reference level in 1-3-10 multiples.
- Use the front-panel data keys to enter exact values. Terminate data-key entry with the **dB** key.
- Use the RPG knob to change the value in small dB increments.

---

**Note** The **REF LVL**, **REF LVL POSN**, and **LOG dB/DIV** functions only affect the results display. They do not affect instrument settings during calibration or measurements.

---

---

## To use Display Markers

Markers can be placed on the measurement traces to read out amplitude and frequency values. Marker functions are found under the **Marker** main (left-hand) menu:

### To turn markers On or Off

Press **MKR NRM On Off** to underline “On” to turn the marker on, or “Off” to remove the marker from the display. Marker frequency and amplitude are shown in the active function area and in the upper right corner of the display. To move the marker:

- Use the **(↑)** and **(↓)** keys to move the marker in one division increments.
- Use the front-panel data keys to enter exact frequency values. Terminate data-key entry with a frequency units key.
- Use the RPG knob to move the marker in single data point increments.

### To use delta markers

Press **DELTA** to place two markers on the display for delta measurements. The difference between the two markers’ frequency and amplitude are shown in the active function area and in the upper right corner of the display. To move the delta marker:

- Use the **(↑)** and **(↓)** keys to move the marker in one division increments.
- Use the front-panel data keys to enter exact frequency values. Terminate data-key entry with a frequency units key.
- Use the RPG knob to move the marker in single data point increments.

### To move the marker to the highest or lowest amplitude

Press **HIGHEST PEAK** to place the active marker at the highest amplitude point on the trace.

Press **MINIMUM POINT** to place the active marker at the lowest amplitude point on the trace.

### To set the reference level equal to the marker amplitude

Press **-> RL** to set the display reference level equal to the marker amplitude value.

### To calculate a marker noise temperature

The equivalent noise temperature in °K of a marker on the noise figure trace can be displayed by pressing the **MARKER TEMP** softkey.

---

**Note**            The marker temp feature does not give useful information when used with the marker delta function or the gain trace.

---

### To move the marker between the noise figure and gain traces

Press **MKR TRA A B C** to underline “A” to place the marker on the noise figure trace, or “B” to place the marker on the gain trace.

---

**Note** Trace A is used for noise figure or output ENR results. Trace B is used for device gain results. Trace C is used during device measurement, and is not a results display.

---

## Testing Results with Limit Lines

For multi-point measurements with graphical results, limit lines can be used for Pass/Fail testing of the noise figure trace (Trace A). Three types of limit line segments are available:

- **FLAT** draws a zero-slope line between the beginning points of two segments, producing limit-line values equal in amplitude for all frequencies between the two points.
- **SLOPE** draws a sloped line between the beginning points of two segments, producing linearly interpolated limit-line values for all frequencies between the two points.
- **POINT** specifies a limit value for the beginning point of a segment only.

### To edit limit line data tables

Press the **Amptd** main (left-hand) menu, then press the **Limit Lines** softkey. The currently active limit line data table is displayed. Refer to Figure 2-9 for an example of a limit line table.

hp 14:27:51 APR 17, 1996  
 RL 0.00 dBm  
 \*ATTEW 0 dB  
 2.00 dB/DIV  
 FAIL  
 SAMPLE \*  
 FREQ VALUE  
 AMPTD VALUE  
 Marker  
 Seg Fixed Freq Lower Amptd Type  
 1 0 Hz -50.00 dBm SLOPE  
 2 20.500 GHz -50.00 dBm SLOPE  
 3  
 TYPE  
 BW, Avg  
 NEXT POINT  
 Measure  
 DELETE POINT  
 State  
 UPPER/  
 LOWER  
 EXIT \*START 100 MHz STOP 205 MHz EDIT  
 NF \*RB 3.00 MHz VB 3.00 MHz \*ST 6.300 sec DONE

Figure 2-18. The Limit Line Table Editor Screen

To enter the limit line data, refer to the following steps:

1. Press **UPPER/LOWER** to select either the upper limit line table or the lower limit line table.
2. Press **FREQ VALUE**, **AMPTD VALUE**, **TYPE** or **NEXT POINT** to move the entry window to a new or existing limit line data point.
3. Change the frequency, amplitude, or line type table values as explained below:
  - Change the frequency value using only the front-panel data keys with the frequency units key.



- Change the amplitude value using only the front-panel data keys with the dBm units key.

---

**Note** Use the dBm units key for entering amplitude, even though the units of noise figure are dB.

---

- Change the line segment type by pressing **TYPE** and then selecting **SLOPE**, **FLAT**, or **POINT**
  - Press the **DELETE POINT** key to delete all the values of a point from the table, regardless of the highlighting position in a data point.
  - Press **EDIT DONE** to return to the previous menu. The edited limit line table is available to test measurement results.
4. To store the limit line table to a memory file, use the **SAVE LIMIT** softkey as explained in the following section.

### To save limit line tables

To save the limit line table data to a memory file, follow the steps below:

1. Press the **State** main (left-hand) menu softkey. Then press the **save** left-hand softkey.
2. Press **MSI IntCard** to underline the save destination you want to use. “Int” chooses the spectrum analyzer internal memory files. “Card” selects the MSIB memory card reader on the front panel of the HP 70004A display.
3. Press **SAVE LIMIT**, then enter the memory register number you wish to use, then press **ENTER** on the front panel.

---

**Note** External card files and internal files 1 to 4999 are available.

Be aware that limit line data is stored as limit line files (L\_5001 to L\_9999) in either internal or external (card) memory.

---

**WARNING** When storing limit line files during normal spectrum analyzer operation, be careful not to write over existing limit line files. ENR tables are stored in files L\_0 through L\_4999. Limit lines are stored in files L\_5000 through L\_9999.

---

### To recall limit line tables

Limit line tables may be recalled from spectrum analyzer memory files, or from memory card files. To recall existing limit line tables, refer to the steps below:

1. Press the **State** main (left-hand) menu softkey. Then press the **recall** left-hand softkey.
2. Press **MSI IntCard** to underline the recall memory you want to use. “Int” chooses the spectrum analyzer internal memory files. “Card” selects the MSIB memory card reader on the front panel of the HP 70004A display.
3. Press **RECALL LIMIT**, then enter the file number you wish to use, then press **ENTER** on the front panel.

---

**Note** Limit line data tables are prefixed “L\_” in spectrum analyzer memory or in memory card memory.

---

To verify the recall of the limit line data, use the table editing technique described earlier in this section.

### **To enable limit line testing**

A noise figure trace on the display can be tested against the limit lines using the following procedure:

1. Press the **Amptd** main (left-hand) menu softkey.
2. Press the **LIMITS On Off** softkey to underline **On** to enable limit line testing or **Off** to disable limit line testing.

The PASS or FAIL message for the limit line test appears at the top center of the display.

---

## **Making Hard-Copies**

Connect the HP 70004A display to an HP-IB printer and use the front-panel **PRINT** key to generate prints.

Consult the HP 70004A Display Operation Manual for details about using printers and plotters.



## Menu Key Descriptions

---

This chapter is a reference that contains the measurement personality menu pages and the menu key descriptions. Refer to Chapter 2, “Making Measurements” for specific measurement procedures that use these keys.

---

### Menu Pages

The menu pages of the HP 70875A Noise Figure Measurements Personality are shown in Figure 3-1 to Figure 3-13. The main menu keys are always present on the left hand side of the display. Keys on the right-hand side of the display are of two types:

1. Key labels which are in all capital letters are either immediately executed (e.g. `MEASURE NF`) or require a subsequent keyboard numeric input (e.g. `POINTS`).
2. Key labels which contain lower-case letters reassign new key labels to the right-hand softkeys, thus leading to a new menu page (e.g. `EditSrc ENR`).

hp 15:57:15 APR 16, 1996  
RL 0.00 dBm

Freq	*ATTEN 0 dB 2.00 dB/DIV									POINTS
Amptd	POINTS 21							SAMPLE *		FrqConv Yes No
Marker										START FREQ
BW,Avg										STOP FREQ
Measure										
State										
EXIT	*START 100 MHz									STOP 205 MHz
NF	*RB 3.00 MHz			VB 3.00 MHz			*ST 7.000 sec			

**Figure 3-1. The Frequency (non-converting) Menu Page**

hp 15:58:04 APR 16, 1996  
RL 0.00 dBm

Freq	*ATTEN 0 dB 2.00 dB/DIV									POINTS
Amptd	POINTS 21							SAMPLE *		FrqConv Yes No
Marker										RF STRT FREQ
BW,Avg										RF STOP FREQ
Measure										IF STRT FREQ
State										IF STOP FREQ
EXIT	*START 3.70 GHz									STOP 4.23 GHz
NF	*RB 3.00 MHz			VB 3.00 MHz			*ST 7.000 sec			

**Figure 3-2. The Frequency (converting) Menu Page**

hp 16:00:14 APR 16, 1996  
RL 0.00 dBm

Freq	*ATTEN 0 dB								REF LVL
	2.00 dB/DIV								
Amptd	REF LEVEL						SAMPLE *		ATTEN
	0.00 dBm								
Marker									LOG dB/DIV
BW,Avg									REF LVL POSN
Measure									LIMITS On Off
State									Limit Lines
EXIT	*START 3.70 GHz						STOP 4.23 GHz		
NF	*RB 3.00 MHz	VB 3.00 MHz					*ST 7.000 sec		

Figure 3-3. The Amplitude Menu Page

hp 14:27:51 APR 17, 1996  
RL 0.00 dBm

Freq	*ATTEN 0 dB			FAIL					FREQ VALUE
	2.00 dB/DIV								
Amptd							SAMPLE *		AMPTD VALUE
Marker	Seg	Fixed Freq	Lower Amptd	Type					TYPE
	1	0 Hz	-50.00 dBm	SLOPE					
	2	20.500 GHz	-50.00 dBm	SLOPE					
	3								
BW,Avg									NEXT POINT
Measure									DELETE POINT
State									UPPER/ LOWER
EXIT	*START 100 MHz						STOP 205 MHz		EDIT
NF	*RB 3.00 MHz	VB 3.00 MHz					*ST 6.300 sec		DONE

Figure 3-4. The Limit Lines Edit Menu Page

hp 14:28:53 APR 17, 1996

RL 0.00 dBm MKR #1 FRQ 150 MHz

Freq	*ATTEN 0 dB					0.00 dBm	<b>MKR NRH</b>
	2.00 dB/DIV						On Off
Amptd	MARKER					SAMPLE *	DELTA
	150 MHz						
	0.00 dBm						
Marker	1						HIGHEST PEAK
BW,Avg							MINIMUM POINT
Measure							-> RL
State							MARKER TEMP
EXIT	*START 100 MHz					STOP 205 MHz	MKR TRA
NF	*RB 3.00 MHz	VB 3.00 MHz				*ST 6.300 sec	A B C

Figure 3-5. The Marker Menu Page

hp 14:29:41 APR 17, 1996

RL 0.00 dBm MKR #1 FRQ 150 MHz

Freq	*ATTEN 0 dB					0.00 dBm	<b>RES BW</b>
	2.00 dB/DIV						
Amptd	RES BANDWIDTH					SAMPLE *	AVG TIME
	3.000 000 MHz						
Marker							AVGTIME AutoMan
BW,Avg							T*BW PRODUCT
Measure							
State							
EXIT	*START 100 MHz					STOP 205 MHz	
NF	*RB 3.00 MHz	VB 3.00 MHz				*ST 6.300 sec	

Figure 3-6. The Bandwidth & Averaging Menu Page



hp 14:30:23 APR 17, 1996

RL 0.00 dBm MKR #1 FRQ 150 MHz

Freq	*ATTEN 0 dB						0.00 dBm	MEASURE
	2.00 dB/DIV							NF
Amptd							SAMPLE *	CAL
Marker								MEASURE
								NF & GAIN
BW, Avg								MEASURE
								ENR
Measure								SWEEP
								ContSgl
State								PlotPts
								On Off
EXIT	*START 100 MHz						STOP 205 MHz	ABORT
NF	*RB 3.00 MHz	VB 3.00 MHz					*ST 6.300 sec	

Figure 3-7. The Measure Menu Page

hp 14:31:24 APR 17, 1996

RL 0.00 dBm MKR #1 FRQ 150 MHz

Freq	*ATTEN 0 dB						0.00 dBm	DEFAULT
	2.00 dB/DIV							STATE
Amptd							SAMPLE *	recall
Marker								save
BW, Avg								Ext
								Losses
Measure								EditSrc
								ENR
State								Verify
								Specs
EXIT	*START 100 MHz						STOP 205 MHz	MORE
NF	*RB 3.00 MHz	VB 3.00 MHz					*ST 6.300 sec	1 of 2

Figure 3-8. The State Menu Page 1




Figure 3-9. The Recall Menu Page




Figure 3-10. The Save Menu Page

hp 14:33:54 APR 17, 1996  
 RL 0.00 dBm MKR #1 FRQ 150 MHz

Freq	*ATTEN 0 dB						0.00 dBm	FREQ VALUE
	2.00 dB/DIV							
Amptd	FREQ VALUE						SAMPLE *	AMPTD VALUE
	10 MHz							
Marker	Seg	Fixed Freq	Upper Amptd	Type				NEXT POINT
	1	10.0 MHz	19.00 dBm	SLOPE				
	2	100 MHz	19.00 dBm	SLOPE				
	3	1.000 GHz	19.00 dBm	SLOPE				
BW,Avg	4	2.000 GHz	19.00 dBm	SLOPE				LAST POINT
	5	3.000 GHz	19.00 dBm	SLOPE				
	6	4.000 GHz	19.00 dBm	SLOPE				
Measure	7	5.000 GHz	19.00 dBm	SLOPE				DELETE POINT
	8	6.000 GHz	19.00 dBm	SLOPE				
	9	7.000 GHz	19.00 dBm	SLOPE				
State	10	8.000 GHz	19.00 dBm	SLOPE				
	11	9.000 GHz	19.00 dBm	SLOPE				
EXIT	*START 100 MHz			STOP 205 MHz			EDIT	
NF	*RB 3.00 MHz		VB 3.00 MHz	*ST 6.300 sec			DONE	

Figure 3-11. The Edit ENR Source Menu Page

hp 14:34:46 APR 17, 1996  
 RL 0.00 dBm MKR #1 FRQ 150 MHz

Freq	*ATTEN 0 dB						0.00 dBm	PM MSIB COLUMN
	2.00 dB/DIV							
Amptd							SAMPLE *	DEFAULT TEST
Marker								TEST POINTS
BW,Avg								CAL
Measure								START TEST
State								CONT TEST
EXIT	*START 100 MHz			STOP 205 MHz			PREV	
NF	*RB 3.00 MHz		VB 3.00 MHz	*ST 6.300 sec			MENU	

Figure 3-12. The Verify Specs Menu Page




Figure 3-13. The State Menu Page 2

---

## Menu Key Descriptions

In this section, in alphabetical order, the menu keys are listed and described. Refer to the previous illustrations in Figure 3-1 to Figure 3-13 for the location of the HP 70875A Noise Figure Measurements Personality keys.

ABORT	Select this key in the <b>Measure</b> menu to interrupt a calibration or measurement sequence that is currently in progress.
AMPTD VALUE	Select this key in the <b>Limit Lines</b> or <b>Edit SrcENR</b> menus to highlight an entry in the amplitude column of the limit line table for editing.
ATTEN	Select this key in the <b>Amptd</b> menu to display or change the spectrum analyzer RF input attenuator setting. When the preamp is enabled, an attenuation value of 0 will generally provide the best system noise figure. However, high gain devices can have high levels of output noise power which can overload the preamp and cause measurement inaccuracy. In this case, the preamp can be disabled and the input attenuator should be set to prevent overloading of the input mixer in the RF section.

---

**Note** In using the **ATTEN** softkey, values can be entered that do not correspond to actual attenuator hardware capability. Refer to the spectrum analyzer operation manual to determine valid attenuator range and step size. Check the annotation in the upper left hand corner of the display for the actual RF attenuator state.

---

AVG TIME	Select this key in the <b>BW, Avg</b> menu to display or change the measurement averaging time. You can use the average-time value to reduce the effects of jitter on measurement repeatability. The longer the average time, the better the jitter reduction. The range of values is from 100 ms to 1000 s, in steps of 0.1 s below 1 s, and steps of 1 s above. With the <b>AVG TIME AutoMan</b> softkey set to AUTO, the value of AVG TIME is determined by the value of <b>T*BW PRODUCT</b> divided by <b>RES BW</b> .
----------	--

AVG TIME AutoMan	Select this key in the <b>BW, Avg</b> menu to set the averaging time-resolution bandwidth coupling mode.  When <b>AVG TIME Auto</b> is selected, the value of <b>AVG TIME</b> is determined by the value of <b>T*BW PRODUCT</b> divided by <b>RES BW</b> .  When <b>AVG TIME Man</b> is selected, the value of <b>AVG TIME</b> can be set independently from the settings of <b>T*BW PRODUCT</b> and <b>RES BW</b> .
------------------	--

BEEPER On Off	Select this key on page 2 of the <b>State</b> menu to turn the end-of-measurement beeper ON or OFF. The beeper is useful in notifying the operator that the measurement has completed. The beeper hardware is in the HP 70004A Display.
---------------	---

CAL	Select this key in the <b>Measure</b> menu to initiate the system calibration routine. The calibration procedure minimizes the effects of losses, noise, and gain factors due strictly to the measurement setup. It must
-----	--

be performed prior to corrected Noise Figure and Gain measurements or ENR measurements.

CONT TEST

Select this key in the **Verify Specs** menu to continue the verification test sequence after the input noise power to the spectrum analyzer has been adjusted.

DEFAULT STATE

Select this key in the state menu to restore default configuration parameters. These parameters are listed in Table 3-1 on the following page:

**Table 3-1.  
Noise Figure Personality Default Parameters**

<b>Parameter</b>	<b>Default Setting</b>
Attenuator	0 dB
Average Time	Auto mode
Beeper Mode	ON
Frequency Conversion	Off
IF Start Frequency(conversion)	1.950 GHz
IF Stop Frequency(conversion)	1.450 GHz
Input Loss	0.0 dB
Limitest	Off
Mass Storage	Memory Card (MSIB)
Output Loss	0.00 dB
Plot Points	On
Points	21
Preamplifier	Enabled
Reference Level	0 dB
Reference Level Position	0
Resolution Bandwidth	3 MHz
RF Start Frequency(conversion)	3.70 GHz
RF Stop Frequency(conversion)	4.20 GHz
Start Frequency (non conversion)	100 MHz
Stop Frequency (non conversion)	200 MHz
Source Case Temperature	17.0°C
Source Loss	0.00 dB
Sweep Mode	Single
Time-BW Product	1 MHz–sec
Vertical Scale	2 dB/div

DEFAULT TEST

Select this key in the **Verify Specs** menu to restore default test configuration parameters. These parameters are listed in Table 3-2 on the following page:

**Table 3-2. Verification Test Default Parameters**

Parameter	Default Setting
Attenuator	0 dB
Average Time	Auto mode
Frequency Conversion	Off
Input Loss	0.0 dB
Limit Test	On
Mass Storage	internal
Output Loss	0.00 dB
Plot Points	On
Points	31
Preamplifier	Disabled
Reference Level	0 dB
Reference Level Position	5
Resolution Bandwidth	3 MHz
Start Frequency (non conversion)	320 MHz
Stop Frequency (non conversion)	320 MHz
Source Case Temperature	17.0°C
Source Loss	0.00 dB
Sweep Mode	Single
Time-BW Product	3 MHz–sec
Vertical Scale	0.5 dB/div

DELETE POINT

Select this key in the **Limit Lines** or **Edit SrcENR** menus to delete a data point in the limit line table.

DELTA

Select this key in the **Marker** menu to turn the trace delta marker ON or OFF. The delta marker can then be positioned relative to the reference marker to make delta measurements.

DLP VERSION

Select this key on page 2 of the **State** menu to display the software revision date of the Noise Figure Measurements personality software.

EDIT DONE

Select this key in the **Limit Lines** or **Edit SrcENR** menus to exit the limit line table editing mode.

EditSrc ENR

Select this key in the **State** menu to enter the noise source ENR editing mode.

EXIT DLP

Pressing this main menu key will cause the analyzer to exit the Noise Figure Measurements personality and return to the last spectrum analyzer state that existed before the personality was entered.

Ext Losses

Select this key in the **State** menu to select the external losses menu.

FREQ VALUE	Select this key in the <b>Limit Lines</b> or <b>Edit SrcENR</b> menus to highlight an entry in the frequency column of the limit line table for editing.
FrqConv Yes No	Select this key in the <b>Freq</b> menu to choose the frequency conversion mode. The default setting is off, or <b>NO</b> . Set frequency conversion to <b>YES</b> for testing receivers, mixers, or other frequency conversion devices. The <b>FrqConv Yes</b> menu includes RF and IF start- and stop-frequency parameters. The frequency span of the RF and IF values must equal. The default values are listed in Table 3-1 in this section.
HIGHEST PEAK	Select this key in the <b>Marker</b> menu to position the active trace marker to the highest amplitude point on the trace.
IF STOP FREQ	Select this key in the <b>Freq</b> menu when conversion is set to YES. Enter the IF stop frequency for frequency conversion measurements. The valid range of frequencies is equal to the frequency range of the spectrum analyzer.
IF STRT FREQ	Select this key in the <b>Freq</b> menu when conversion is set to YES. Enter the IF start frequency for frequency conversion measurements. The valid range of frequencies is equal to the frequency range of the spectrum analyzer.
INPUT LOSS	Select this key in the <b>Ext Losses</b> menu to enter the dB loss value located at the input of the device under test. The loss is entered and due to components required in the test setup for making measurements, but the components were <i>not</i> included in test-setup calibration.
INT AMP On Off	Select this key in the second page of the <b>State</b> menu to enable the system preamp (ON) or bypass the preamp (OFF).
LAST POINT	Select this key in the <b>Edit SrcENR</b> menu to move the entry window to the last data point in the table.
Limit Lines	Select this key in the <b>Amptd</b> menu to enter the limit line editing mode.
LIMITS On Off	Select this key in the <b>Amptd</b> menu to turn the limit testing function <b>On</b> or <b>Off</b> .
LOG dB/DIV	Select this key in the <b>Amptd</b> menu to display or change the measurement scale for the results display.
MARKER TEMP	Select this key in the <b>Marker</b> menu to display the marker noise temperature in °K.
MEASURE ENR	Select this key in the <b>Measure</b> menu to initiate a DUT output Excess Noise Ratio measurement sequence. Before this measurement can begin, the measurement configuration and system calibration must have been completed.
MEASURE NF	Select this key in the <b>Measure</b> menu to initiate the uncorrected noise figure measurement sequence.



---

**Note**           Uncorrected noise figure measurements can be made, however, there will be no gain measurement trace.

---

MEASURE NF&GAIN   Select this key in the **Measure** menu to initiate the corrected noise figure and gain measurement sequence. Before this measurement can begin, the measurement configuration and system calibration must have been completed.

MINIMUM POINT     Select this key in the **Marker** menu to position the active trace marker to the lowest amplitude point on the trace.

MKR NRM On Off     Select this key in the **Marker** menu to turn the trace marker ON or OFF.

MKR TRA A B C      Select this key in the **Marker** menu to move the marker to trace A, B, or C.

---

**Note**           Trace A is used for noise figure or output ENR results. Trace B is used for device gain results. Trace C is used during device measurement, and is not a results display.

---

MORE 1 of 2         Select this key in the **State** menu to display more state choices. The **MORE 1 of 2** key displays the following menu:

- INT AMP On Off
- SOURCE TEMP
- BEEPER On Off
- DLP VERSION
- MORE 2 of 2

MORE 2 of 2         Select this key in the **State** menu to return to the previous menu page.

MSI IntCard         Select this key in the **recall** menu to select the location for storing or retrieving files. When INT is selected, internal analyzer memory will be accessed. When CARD is selected, the external MSIB device (memory card reader on the front panel of the HP 70004A display) is accessed.

NEXT POINT         Select this key in the **Limit Lines** or **Edit SrcENR** menus to move the entry window to the next data point in the limit line table.

OUTPUT LOSS        Select this key in the **Ext Losses** menu to enter loss compensation factors that exist due to devices connected between the output connector of the device under test and the system preamplifier and present during the measurement. These devices include cables and isolators that are attached during the measurement, but *not during calibration*.

PlotPts On Off      Select this key in the **Measure** menu to turn the end-of-measurement results plotting ON or OFF.

PM MSIB COL         Select this key in the **Verify Specs** menu to enter the MSIB column address of the HP 70100A Power Meter module used in the verification test.

---

**Note** The MSIB column address of the Power Meter module must be entered before starting the verification test.

---

**POINTS** Select this key from the **Freq** menu to enter the number of frequency points to measure. The values from the points measured are used in noise figure and gain calculations. You can measure from 1 to 800 points. The personality sets points to the nearest actual number as listed below:

Number Entered	Actual Number Points Measured
1	1 point
2	1 point
$3 \leq N \leq 800$	N points
$800 < N$	800 points

**PREV MENU** Select this key to return to the previously displayed menu.

**recall** Select this key in the **State** menu to select the recall menu.

**RECALL ENR** Select this key in the **recall** menu to select and recall a noise source ENR table from memory. An ENR table can be recalled from an existing table stored in the internal memory or from a table stored on a memory card, depending on the setting of MSI. The recalled table is then applied in all subsequent measurements. The valid range of ENR files is 1 to 4999.

**RECALL LIMIT** Select this key in the **recall** menu to select and recall a limit line table from memory. A limit line table can be recalled from an existing table stored in the internal memory or from a table stored on a memory card, depending on the setting of MSI. The recalled table is then compared against trace A data when limit testing is turned ON. The valid range of limit line files is 1 to 4999.

**REF LVL** Select this key in the **Amptd** menu to display or change the reference level for the results display.

**REF LVL POSN** Select this key in the **Amptd** menu to display or change the reference level position for the results display.

**RES BW** Select this key in the **BW, Avg** menu to display or change the measurement IF bandwidth. The valid range is 1 KHz to 3 MHz.

**RF STOP FREQ** Select this key in the **Freq** menu when **Freq Conv** is set to **Yes**. Display or change the RF stop frequency value for a measurement. The valid range of RF frequencies is from 0.0 kHz to 1E26 Hz.

**RF STRT FREQ** Select this key in the **Freq** menu when **Freq Conv** is set to **Yes**. Display or change the RF start frequency value for a measurement. The valid range of RF frequencies is from 0.0 kHz to 1E26 Hz.

**-->RL** Select this key in the **Marker** menu to set the results display reference level equal to the active marker amplitude.

**save** Select this key in the **State** menu to select the save menu.

SAVE ENR	Select this key in the <b>save</b> menu to save a noise source ENR table to memory. An ENR table presently in use by the analyzer can be saved to internal memory or to the external memory card, depending on the setting of MSI. The valid range of ENR file numbers is 1 to 4999.
SAVE LIMIT	Select this key in the <b>save</b> menu to save a limit line table to memory. A limit line table presently in use by the analyzer can be saved to internal memory or to the external memory card, depending on the setting of MSI. The valid range of limit line file numbers is 1 to 4999.
SOURCE LOSS	Select this key in the <b>Ext Losses</b> menu to enter the loss compensation factors that exist due to the noise source.
SOURCE TEMP	Select this key in the second page of the <b>State</b> menu to enter the noise-source case temperature. The range of this parameter is 0°C to 1000°C. The default temperature value is 17°C.

---

**Note** If you are testing devices in extreme temperature conditions, the value you enter serves as a correction to measurement results.

---

START FREQ	Select this key in the <b>Freq</b> menu to enter the start frequency setting of a non-frequency conversion measurement. The valid range of frequencies is equal to the frequency range of the spectrum analyzer.
START TEST	Select this key in the <b>Verify Specs</b> menu to initiate the verification test sequence.
STOP FREQ	Select this key in the <b>Freq</b> menu to enter the stop frequency setting of a non-frequency conversion measurement. The valid range of frequencies is equal to the frequency range of the spectrum analyzer.
SWEEP ContSgl	Select this key in the <b>Measure</b> menu to select either CONTINUOUS or SINGLE sweep measurements. The continuous mode is generally useful only in the single point measurement mode, with <b>POINTS</b> set to 1.
T*BW PRODUCT	Select this key in the <b>BW, Avg</b> menu to adjust the time-bandwidth product. This product is the averaging time multiplied by the measurement bandwidth in Megahertz-seconds. Changing the time-BW product while averaging mode is set to AUTO causes the measurement time to change, but not the measurement bandwidth.
TEST POINTS	Select this key in the <b>Verify Specs</b> menu to display or change the number of measurement points in the verification test.
TYPE	Select this key in the <b>Limit Lines</b> menu to select an entry in the type column of the limit line table for editing. Three types of limit line segments are available: <ul style="list-style-type: none"> <li>■ <b>FLAT</b> draws a zero-slope line between the beginning points of two segments, producing limit-line values equal in amplitude for all frequencies between the two points.</li> <li>■ <b>SLOPE</b> draws a sloped line between the beginning points of two segments, producing linearly interpolated limit-line values for all frequencies between the two points.</li> </ul>

- POINT specifies a limit value for the beginning point of a segment only.

UPPER/LOWER

Select this key in the Limit Lines menu to select the upper or lower limit line table for editing.

Verify Specs

Select this key in the State menu to select the verify specifications menu.

## **Specifications, Characteristics, and Verification**

---

This chapter contains Table 4-1 measurement specifications and characteristics as well as procedures to verify the specifications.

The chapter is organized as follows:

- The table of specifications and characteristics
- The performance verification test

---

## Specifications and Characteristics

The specifications in Table 4-1 apply only for the following configuration:

- HP 70875A Noise Figure Measurements Personality
- HP 70908A RF Section (22 GHz) or HP 70909/10A RF Section (26.5 GHz)
- HP 70900B LO/Control Section with firmware Rev.940120 (B.05.00) or later
- HP 70903A IF Section
- HP 70902A IF Section
- HP 70620B Opt.001 Preamp
- HP 346B (18 GHz) or HP 346C (26.5 GHz) Noise Source

All specifications apply over 0-55°C. The Noise Figure Measurements Personality specifications are valid after 2 hours of storage at a constant temperature, within the operating temperature range, 30 minutes after the spectrum analyzer is turned on, and after CAL ALL has been run.

**Table 4-1. Specifications**

<b>Specification</b>	<b>Performance Limits</b>	<b>Conditions</b>
<b>Noise Figure Measurement</b> Range Resolution Instrumentation Uncertainty*	0 to 30 dB 0.01 dB  ±0.5 dB ±0.6 dB	10 MHz-2.9 GHz, Measurement Bandwidth = 3 MHz 2.9-26.5 GHz, Measurement Bandwidth = 3 MHz
<b>Gain Measurement</b> Range Resolution Instrumentation Uncertainty*	0 to +30 dB 0.01 dB  ±0.5 dB ±0.6 dB	10 MHz-2.9 GHz, Measurement Bandwidth = 3 MHz 2.9-26.5 GHz, Measurement Bandwidth = 3 MHz
<b>Input</b> Frequency Range  System Noise Figure    Input SWR	10 MHz to 22 GHz 10 MHz to 26.5 GHz  < 11 dB < 12 dB < 18 dB < 21 dB  < 2.4:1 < 2.2:1 < 3.0:1	Using HP 70908A RF Section Using HP 70909A or 70910A RF Section  10 MHz - 2.9 GHz 2.9 - 12.8 GHz 12.8 - 22.0 GHz 22.0 - 26.5 GHz  10 MHz - 2.9 GHz 2.9 - 12.8 GHz 12.8 - 26.5 GHz
<b>IF Processing</b> IF Bandwidths Noise Averaging	1 KHz to 3 MHz 20 mSec to 1000 Sec	in 10 percent increments
* For DUT NF ≤ 15 dB and (DUT NF + DUT gain) ≥ System Noise Figure		

---

## System Performance Verification

The procedure in this section verifies the instrumentation accuracy of the spectrum analyzer for noise figure measurements. The procedure measures the analyzer's log scale fidelity using a noise signal as the source. All other items in Table 4-1 are standard spectrum analyzer specifications and are verified using the procedures listed in the Installation and Verification Manual for the particular spectrum analyzer model being used.

### Verification Test Description

Performance verification of the spectrum analyzer hardware is achieved by measuring the accuracy of changes in noise power over an input range of 30 dB in 1 dB steps.

The test measures the deviation of the spectrum analyzer noise power measurement compared to a power meter measurement. The peak-to-peak deviation over the 30 dB measurement range is the instrumentation uncertainty of the spectrum analyzer for making noise figure measurements.

The test begins with a band-limited noise signal applied to the spectrum analyzer input. The input Excess Noise Ratio is measured for this first point. Then the noise level is reduced in 1 dB increments, measuring ENR with the spectrum analyzer and input power with the power meter at each point. The difference between the spectrum analyzer and the power meter measurements are plotted, normalized to the first measurement point. Limit lines are drawn on the display, and a PASS/FAIL indication is shown, depending on the results of the test.

### Related Spectrum Analyzer Specifications

Log Scale Fidelity

### Equipment required for the measurement

The performance verification test equipment is listed below:

HP 70000 Series Spectrum Analyzer .....	HP 71100C/71209A/71210C
Noise Source .....	HP 346C
Power Meter .....	HP 70100A
Dual Amplifier (two required) .....	HP 8447A, Option 001
Low Power Sensor .....	HP 8485D
321.4 MHz Bandpass Filter .....	9135-0252
Power Splitter .....	HP 11667B
Coaxial, 1 dB Step Attenuator .....	HP 8494A, Option 001
Coaxial, 10 dB Step Attenuator .....	HP 8595A, Option 001
Type-N Interconnect Kit .....	HP 11716A
Termination 50 Ohm BNC(M) .....	1250-0207

#### Cables

50Ω BNC Cable,(23 cm) (four required) .....	HP 10502A
SMA Cable,(75 cm) .....	5021-9039

#### Adapters

SMA (m) to BNC (f), (three required) .....	1250-1200
Type N (m) to BNC (f) .....	1250-1472
Type N (m) to SMA (f) .....	1250-1250



## Calibrate the Spectrum Analyzer

The spectrum analyzer should be calibrated prior to the verification test. To do this, the analyzer should be in its normal spectrum analyzer mode. Connect the Calibrator output on the HP 70900B module to the RF Input on the preamplifier module. Then press **(MENU)**, **Amptd**, **CAL ALL**. The calibration routine runs several minutes, depending on the module configuration. The routine ends when the End of Calibration message appears on the display.

## Zero and Calibrate the Power Meter

Follow the instructions in the HP 70100A Power Meter Operating Manual to zero and calibrate the power sensor. Make sure that the correct Cal Factor Table for the sensor in use has been stored in the sensor table of the HP 70100A.

---

**CAUTION** Do not calibrate the HP 8485D without the reference attenuator. The reference attenuator prevents damage to the HP 8485D low power sensor.


---

## Calibrate For ENR Measurements

Connect the noise source to the Preamplifier Module RF input as shown in Figure 4-1. If the analyzer is not already in noise figure measurement mode, press the **(USER)** front panel key, then press the **NF\_GAIN DLP** softkey to invoke the noise figure measurements personality.

If you have not previously entered the ENR table for the noise source that you are using, do so now using the procedure given in Chapter 2.

Enter the spec verification menu by pressing **State**, **Verify Specs**. Press the **DEFAULT TEST** softkey to set the analyzer to a default state that can be used for performing the verification. Press the **CAL** softkey to perform a system calibration. The routine ends when the Calibration done, Ready to measure DUT message appears on the display.




pa72a

**Figure 4-1. Calibration Setup for ENR Measurements**

## Perform the Verification Test

Connect the equipment as shown in Figure 4-2. Note that the noise source is not used in this setup. Then use the following procedure:

1. Select the power meter on the HP 70004A display. Set the power meter measurement frequency to 320 MHz. Then adjust the step attenuators so that the power meter reads within 1 dB of -30 dBm.
2. Select the spectrum analyzer on the HP 70004A display. In the spec verification menu, press the **PM MSIB COLUMN** softkey. The personality will display the expected MSIB column address for the HP 70100A Power Meter module. If the displayed address is not the correct address for the power meter that is to be used in the measurement, key in the correct address and press **ENTER**. This establishes an MSIB communications link between the spectrum analyzer and the power meter.
3. Press the **START TEST** softkey. The message **Connect SA and PM to Splitter, Press CONT** will appear on the display. Press the **CONT TEST** softkey to initiate an ENR measurement. When the measurement is complete, the message **Adjust Noise Power, Press CONT TEST** will appear on the display. The ENR measurement result will appear at the lower left corner of the display.
4. Increase the present attenuator setting by 1 dB (which may require adjustment of both the 1 dB and 10 dB step attenuators). Press the **CONT TEST** softkey to initiate another ENR measurement. Wait for the message **Adjust Noise Power, Press CONT TEST** to appear on the display. The displayed ENR measurement result should be approximately 1 dB less than the previous value. Repeat this step until the message **ENR measurement error vs Power Meter** appears on the display. This completes the verification test.



pa711b

**Figure 4-2. Verification Test Setup**

### Interpreting the Verification Test Results

An example verification test result display is shown in Figure 4-3. Trace A in the display is a measurement of the error in the spectrum analyzer's measurement of noise power relative to the noise power measurements made by the power meter. The vertical axis represents the error of the spectrum analyzer measurement in dB units. The horizontal axis represents the relative power levels at which the measurements were made, with the highest power level (first measurement) at the left and the lowest power level (last measurement) at the right.

Specification limit lines for the analyzer's instrumentation accuracy are also displayed. A PASS message at the top center of the display indicates that the measured performance is within the specifications. A FAIL message indicates that the analyzer has failed the test.




Figure 4-3. Example Verification Test Result

---

## **If Verification Fails**

If the verification test does not pass, refer to the following tips:

- Be sure that the spectrum analyzer, power meter and noise figure calibration routines were completed just prior to running the verification test.
- Leave the amplifiers on overnight and just before beginning service testing, if possible. A small change in temperature can cause a large change in noise amplitude.
- Be sure the spectrum analyzer has been powered on for 2 hours at a stable, ambient temperature before beginning verification testing.
- Try to complete the verification test in one sitting.
- It may be helpful to write down the attenuator settings and check them off as they are used to prevent the possibility of repeated or missed steps.



## **If You Have a Problem**

---

This chapter contains a table of several messages that you may encounter as you use the measurement personality. Depending on your measurement complexity, additional messages may occur that are not listed here. If necessary, contact any HP Sales or Service Office.

Information about packaging and general problem with suggested solutions are also included.

---

### **Measurement Personality Messages**

The messages in Table 5-1 indicate that an operation error has occurred that could affect measurement accuracy. The messages in Table 5-2 provide information to you and typically appear during measurement personality operation.

**Table 5-1. Measurement Personality Error Messages**

<b>Message Displayed (numeric order)</b>	<b>Description</b>
ERR 3210 Noise too high	<p>The measurement personality has encountered a signal that is above the expected measurement range. The measured signal must not exceed the analyzer reference level minus 10 dB. If the DUT gain is too high, attenuate its output and enter the output loss correction. If a spurious signal is present, eliminate the signal or change the frequency range or points to “miss” the signal. If your measurement is at low frequencies, chose a narrow enough measurement bandwidth to avoid the 0 Hz spectrum analyzer LO feedthrough signal.</p> <p>You can also press the <b>EXIT NF</b> softkey, switch to spectrum analyzer mode, and evaluate the information in the signal you are measuring. Press <b>(USER)</b> key and the <b>NF_GAIN DLP</b> softkey to return to the noise figure measurement configuration you were using.</p>
ERR 3211 System gain too low	<p>During calibration, the measured noise has dropped more than 5 dB below the first point value. If your measurement is at low frequencies, chose a narrow enough measurement bandwidth to avoid the 0 Hz spectrum analyzer LO feedthrough signal.</p>
ERR 3212 CAL needed for meas	<p>A calibration must be performed before a corrected noise figure and gain or ENR measurement can be made. Changes in the measurement configuration prior to these measurements require that you repeat the calibration.</p>
ERR 3213 FrqConv must be OFF	<p>ENR measurements can only be made in the non-frequency converting mode.</p>
ERR 3214 UNCOR warning	<p>The analyzer must be calibrated before entering the Noise Figure Measurements personality. Press the <b>EXIT NF</b> softkey to switch to spectrum analyzer mode. Connect the 300 MHz calibrator signal to the preamp RF input. Press the <b>(MENU)</b> key, then press the <b>Amptd</b>, and <b>CAL ALL</b> softkeys. After the calibration is complete, press the <b>(USER)</b>, then press the <b>NF_GAIN DLP</b> softkey to return to the noise figure measurement configuration you were using.</p>



**Table 5-2. Measurement Personality Information Messages**

<b>Message Displayed (alpha order)</b>	<b>Description</b>
Adjust Noise Power, Press CONT TEST	This messages prompts the operator to adjust the ENR power level during the verification test. See Chapter 4 for details.
Calibrating ...	The calibration routine is beginning. The message identifies the beginning.
Calibration done. Ready to measure DUT.	This message appears when system calibration is finished. Connect the device to be tested and begin making measurements.
Connect DUT OUTPUT to SA IN, Press ENR	After pressing the <b>MEASURE ENR</b> measurement softkey, be sure to connect the output of the Device Under Test to the spectrum analyzer (preamp) RF input, then press the <b>MEASURE ENR</b> softkey again.
Connect NS to DUT INPUT, Press MEAS NF	After pressing the <b>MEASURE NF</b> measurement softkey, be sure to connect the noise source to the Device Under Test input, then press the <b>MEASURE NF</b> softkey again.
Connect NS to DUT INPUT, Press NF&GAIN	After pressing the <b>MEASURE NF&amp;GAIN</b> measurement softkey, be sure to connect the noise source to the Device Under Test input, then press the <b>MEASURE NF&amp;GAIN</b> softkey again.
Connect NS to SA INPUT, Press CAL	After pressing the <b>CAL</b> measurement softkey, be sure to connect the noise source to the spectrum analyzer (preamp) RF input, then press the <b>CAL</b> softkey again.
Connect SA and PM to Splitter, Press CONT	After pressing the <b>START TEST</b> softkey, be sure to connect the Spectrum Analyzer (preamp) RF input and the Power Meter sensor to the splitter, then press the <b>CONT TEST</b> softkey. See Chapter 4 for details on the verification test.
Default State Restored	This message appears after the <b>DEFAULT STATE</b> softkey has been pressed, indicating that the noise figure measurements state has been restored.

**Table 5-2. Measurement Personality Information Messages (continued)**

<b>Message Displayed (alpha order)</b>	<b>Description</b>
ENR (corrected) Measurement Complete	The ENR measurement has completed.
ENR measurement error vs Power Meter	The performance verification test has completed. The displayed results show ENR measurement error vs ENR power level.
EXIT NF, then CAL before using NF&GAIN	The spectrum analyzer must be calibrated before accurate noise figure measurements can be made. See Error Message 3214 for details.
Loading last instrument state ...	The Noise Figure Measurements Personality is loading and restoring the previous noise figure measurement state.
Making PM Measurement	During the performance verification test, this message appears indicating that the Power Meter measurement is in progress.
Measurement ABORTED	A measurement error has occurred that would affect results accuracy. The measurement has stopped.
Measuring ENR	The ENR measurement is running in the single sweep mode.
Measuring ENR (Continuous)	The ENR measurement is running in the continuous sweep mode.
Measuring NF and GAIN	The Noise Figure and Gain measurement is running in the single sweep mode.

**Table 5-2. Measurement Personality Information Messages (continued)**

<b>Message Displayed (alpha order)</b>	<b>Description</b>
Measuring NF and GAIN (Continuous)	The Noise Figure and Gain measurement is running in the continuous sweep mode.
Measuring uncorr'd NF	The uncorrected Noise Figure measurement is running in the single sweep mode.
Measuring uncorr'd NF (Continuous)	The uncorrected Noise Figure measurement is running in the continuous sweep mode.
NF and GAIN Measurement Complete	The Noise Figure and Gain measurement has completed.
NF (uncorrected) Measurement Complete	The uncorrected Noise Figure measurement has completed.
Normal Spectrum Analyzer Operation	This message appears after the <b>EXIT NF</b> softkey has been pressed, indicating that the previous spectrum analyzer state has been restored.
Perform CAL before ENR measurement	The CAL routine must be run before an ENR measurement can be made.
Perform CAL before NF&Gain measurement	The CAL routine must be run before a corrected Noise Figure and Gain measurement can be made.
Perform CAL before STARTing TEST	The CAL routine must be run before the verification test can be run.

**Table 5-2. Measurement Personality Information Messages (continued)**

<b>Message Displayed (alpha order)</b>	<b>Description</b>
PM Measurement Complete	During the performance verification test, this message appears indicating that the Power Meter measurement is complete.
Set PM MSIB Column	Using the numeric keypad, press the MSIB column address of the HP 70100A Power Meter module to be used in the verification test, then press <b>ENTER</b> .
Set Power Meter MSIB COLUMN first	The personality has not found a power meter module at the existing address. Using the numeric keypad, press the MSIB column address of the HP 70100A Power Meter module to be used in the verification test, then press <b>ENTER</b> .

---

## Returning the Instrument for Service

In the event that you need to return your spectrum analyzer to the factory for service on the noise figure and gain measurement personality, refer to the steps below:

- Record any error messages that were displayed and enclose a copy of this information with the instrument being returned.
- Fill in a blue service-repair card located at the end of this chapter. Enclose the card with the instrument being returned.
- Repackage the HP 70875A measurements personality memory card and spectrum analyzer in the original packaging materials, or with commercially available materials described in the following steps:
  1. Wrap the instrument in anti-static plastic to reduce the potential of electrostatic discharge damage.
  2. Use the original materials or a strong shipping container that is double-walled, corrugated cardboard carton with 159 kg (350 lb) bursting strength. The carton must be both large enough and strong enough to accommodate the instrument and allows at least three to four inches on all sides for packaging materials.
  3. Surround the instrument with at least three to four inches of packaging material, or enough to prevent the instrument from shifting within the carton.

If packaging foam is unavailable, the best alternative is SD-240 Air Cap™ from Sealed Air Corporation in Commerce, CA 90001. The pink-colored Air Cap does not contribute to static charge.

Wrap the instrument several times in this material to both protect the instrument and prevent shifting within the carton.

- Seal the shipping container with strong nylon adhesive tape.

- Mark the shipping container “FRAGILE, HANDLE WITH CARE” to encourage careful handling.
- Retain copies of all shipping papers.
- Ship the instrument to one of the HP Sales or Service offices.



## Programming

---

This chapter is a reference for the HP 70875A Noise Figure Measurements Personality. It is a command dictionary; commands are organized alphabetically.

The chapter contains the following information:

- Reference Tables
- Syntax Conventions
- Command Reference
- Programming Examples

## Reference Tables

Table 6-1 is organized according to function. Table 6-2 lists all measurement personality commands alphabetically.

### Functional Index Table

The functional table groups the commands according to measurement personality function.

To find a programming command that performs a particular function, first refer to the following table where commands are categorized by function. If the command name contains an underscore character, it is a command unique to the Noise Figure Measurements Personality and detailed information on it can be found in the HP 70875A Command Reference. If the command name does not contain an underscore character, it is a standard HP 70900B command and information on it can be found in the HP 70900B Programming Manual.

**Table 6-1. Functional Index**

Function Group	Command	Ranges or Description
Frequency	_PTS	1 to 800 Points. Enter or query the number of frequency points measured.
	_FCONV	1 (conversion on); 0 (conversion off) Select or query the frequency conversion mode.
	_FSTART (non-conversion)	Frequency range of spectrum analyzer Enter or query the measurement start frequency value.
	_FSTOP (non-conversion)	Frequency range of spectrum analyzer Enter or query the measurement stop frequency value.
	_IFSTART	Frequency range of spectrum analyzer Enter or query the measurement IF start frequency.
	_IFSTOP	Frequency range of spectrum analyzer Enter or query the measurement IF stop frequency.
	_RFSTART	0.0 Hz to 1E26 Hz Enter or query the measurement RF start frequency.
	_RFSTOP	0.0 Hz to 1E26 Hz Enter or query the measurement RF stop frequency.



**Table 6-1. Functional Index (continued)**

Function Group	Command	Ranges or Description
Amplitude	_RL	-300 to 300 dB Enter or query the reference level for the results display.
	_AT	0 to maximum RF section attenuation in dB Enter or query RF input attenuator setting.
	_LG	0.01 to 20 dB Enter or query the measurement scale for the results display.
	_RLPOS	0 to 10 Enter or query the reference level position for the results display.
	_LIMITEST	0 (limit line testing turned OFF); 1 (limit line testing turned ON) Activate limit line testing.
	_LIMIDONE	End limit line table edit mode and store table contents into file L5000 in internal memory.
	Marker	MKN
MKD		Position marker relative to reference marker, according to frequency.
MKPK		Position marker at peak on the trace.
MKMIN		Move displayed marker to lowest point on trace.
MK_RL		Set results display reference level equal to marker value for active trace.
_MKTEMP		Query the marker noise temperature in °K.
MKTRACE		Move marker to another trace.

**Table 6-1. Functional Index (continued)**

<b>Function Group</b>	<b>Command</b>	<b>Ranges or Description</b>
BandWidth, Averaging	_BW	1.0 kHz to 3 MHz Enter or query the measurement bandwidth.
	_AVGTIME	100.0 ms to 1000 s Enter or query the measurement averaging time value. The value affects the measurement time per measurement point.
	_TBWAUTO	1 (auto mode selected); 0 manual mode (selected). Select or query the time-bandwidth mode.
	_TBW	0.0001 to 3000 MHz–seconds Enter or query the time-bandwidth product.
Measure	_MNF	Initiate the uncorrected noise figure measurement.
	_CAL	Initiate the noise figure and gain measurement calibration routine.
	_MNFG	Initiate the corrected noise figure and gain measurement.
	_MENR	Initiate the Excess Noise Ratio measurement.
	_CONT	0 (single sweep); 1 (continuous sweep). Enter or query the measurement sweep state.
	_PLOTPTS	0 (measurement results not displayed on screen); 1 (results displayed on screen). Enter or query the results display state.

**Table 6-1. Functional Index (continued)**

Function Group	Command	Ranges or Description
State	_DEFAULTS	Sets all measurement parameters to default values. Refer to Chapter 3, Table 3-1, Noise Figure and Gain Default Parameters, in this guide.
	_RCLENR	1 to 4999 Enter or query the noise source serial number for recalling ENR data from file.
	_RCLLIM	1 to 4999 Enter or query the limit line number for recalling limit line data from file.
	_MSI	0 (internal memory); 1 (memory card). Select location for storing files.
	_SAVENR	1 to 4999 Enter or query the noise source serial number for saving ENR data to file.
	_SAVLIM	1 to 4999 Enter or query the limit line number for saving limit line data to a file.
	_SLOSS	Enter or query the value of loss value affixed to the output of the noise source used in the measurement.

**Table 6-1. Functional Index (continued)**

Function Group	Command	Ranges or Description
	_INLOSS	Enter or query the value of loss that is affixed to the input of the device under test.
	_OUTLOSS	Enter or query the value of loss affixed to the output of the device under test.
	_ENRDONE	End Noise Source ENR table edit mode and store table contents into file L0 in internal memory.
	_PREAMP	0 (preamp disabled); 1 (preamp enabled). Enter or query the internal preamp state.
	_TEMPC	0.0°C to 1000°C Enter or query the noise source case temperature in °C.
	_BEEP	0 (beeper OFF); 1 (beeper ON). Activate end-of-measurement beeper.
	_REVNFG	Query the Noise Figure and Gain software revision date.
Noise Figure Mode Control	_NFMODE	0 (Exit Noise Figure Measurement Mode); 1 (Activate Noise Figure Measurement Mode) Enter or query Noise Figure Measurement mode control.
Output Data	_SENR	Query Noise Source ENR trace data.
	_HI	Query measured DUT output noise power trace data (noise source ON).
	_LOW	Query measured DUT output noise power trace data (noise source OFF).
	_NFSA	Query measured system noise figure trace data (output of _CAL).
	_NF	Query measured DUT corrected noise figure trace data (output of _MNF or _MFNG).
	_GAIN	Query measured DUT gain trace data (output of _MNFG).
	_ENR	Query measured DUT output Excess Noise Ratio trace data (output of _MENR).

## Alphabetical Reference Table

The following table describes the commands available with the noise figure and gain measurements personality.

Prior to using any of the following commands, be sure to send the `_NFMODE 1` command to initiate the noise figure measurements mode.

**Table 6-2. Commands in Alphabetical Order**

Command	Corresponding Key	Description
<code>_AVGTIME</code>	<code>AVG TIME</code>	Enter or query the measurement averaging time value. The value affects the measurement time per measurement point. The range is from 100.0 ms to 1000 s, in steps of 0.1 s below 1 s, and steps of 1 s above.
<code>_AT</code>	<code>ATTENUATOR</code>	Enter or query the RF input attenuator setting.
<code>_BEEP</code>	<code>BEEPER On OFF</code>	Activate end-of-measurement beeper. 0 indicates beeper OFF; 1 indicates beeper ON.
<code>_BW</code>	<code>RES BW</code>	Enter or query the measurement resolution bandwidth.
<code>_CAL</code>	<code>CAL</code>	Initiate system calibration.
<code>_CONT</code>	<code>CONT SWEEP</code>	Enter or query the measurement sweep state. 0 indicates single sweep; 1 indicates continuous sweep.
<code>_DEFAULTS</code>	<code>DEFAULT STATE</code>	Set all measurement parameters to default values.
<code>_ENR</code>	<code>none</code>	Query measured DUT output Excess Noise Ratio trace data (output of <code>_MENR</code> ).
<code>_ENRDONE</code>	<code>EDIT DONE</code>	End Noise Source ENR table edit mode and store table contents into file L0 in internal memory.
<code>_FCONV</code>	<code>FrqConv Yes No</code>	Select or query the frequency conversion mode. A query response of 1 indicates frequency conversion is selected; 0 indicates non-conversion is selected.
<code>_FSTART</code>	<code>START FREQ</code>	Enter or query the measurement start frequency value. All frequency values are converted to Hz.

**Table 6-2. Commands in Alphabetical Order (continued)**

<b>Command</b>	<b>Corresponding Key</b>	<b>Description</b>
_FSTOP	STOP FREQ	Enter or query the measurement stop frequency value. All frequency values are converted to Hz.
_GAIN	none	Query measured DUT gain trace data (output of _MNFG).
_HI	none	Query measured DUT output noise power trace data (noise source ON).
_IFSTART	IF STRT FREQ	In frequency conversion mode, enter or query the measurement IF start frequency.
_IFSTOP	IF STOP FREQ	In frequency conversion mode, enter or query the measurement IF stop frequency.
_INLOSS	INPUT LOSS	Enter or query the value of loss that is affixed to the input of the device under test.
_LIMIDONE	EDIT DONE	End limit line table edit mode and store table contents into file L5000 in internal memory.
_LIMITEST	MSI	Activate limit line testing. 0 indicates limit line testing turned OFF; 1 indicates limit line testing turned ON.
_LG	LOG dB/DIV	Enter or query the measurement scale for the results display.
_LOW	none	Query measured DUT output noise power trace data (noise source OFF).
_MENR	MEASURE ENR	Initiate the Excess Noise Ratio measurement.
MK_RL	-> RL	Set results display reference level equal to marker value for active trace.
_MKTEMP	MARKER TEMP	Query the marker noise temperature in °K.
_MNF	MEASURE NF	Initiate the uncorrected noise figure measurement.

**Table 6-2. Commands in Alphabetical Order (continued)**

<b>Command</b>	<b>Corresponding Key</b>	<b>Description</b>
_MNFG	MEASURE NF&GAIN	Initiate the corrected noise figure and gain measurement.
_MSI	MSI	Select location for storing files. 0 indicates internal memory; 1 indicates HP-MSIB device (memory card).
_NF	none	Query measured DUT corrected noise figure trace data (output of _MNF or _MFNG).
_NFMODE 0	EXIT NF	Disable noise figure mode. Returns analyzer to last state before _NFMODE 1 was invoked.
_NFMODE 1	NF_GAIN DLP	Activates noise figure mode. Initially required before sending or querying noise figure and gain measurement commands.
_NFSA	none	Query measured system noise figure trace data (output of _CAL).
_OUTLOSS	OUTPUT LOSS	Enter or query the value of loss affixed to the output of the device under test.
_PLOTPTS	PLOT PTS	Enter or query the results display state. 0 indicates measurement results will not be displayed on screen; 1 indicates results will be displayed.
_PREAMP	INT PREAMP	Enter or query the internal preamp state. 0 indicates preamp disabled; 1 indicates preamp enabled.


**Table 6-2. Commands in Alphabetical Order (continued)**

<b>Command</b>	<b>Corresponding Key</b>	<b>Description</b>
_PTS	POINTS	Enter or query the number of frequency points measured. If the number of points is set to 1, measurement results will be displayed as text. If the number is greater than 1, the results will be displayed as a graph.
_RCLENR	RECALL ENR#	Enter or query the noise source serial number for recalling ENR data.
_RCLLIM	RCL LIMIT#	Enter or query the limit line number for recalling limit line data.
_REVNFG	DLP VERSION	Query the Noise Figure and Gain software revision date.
_RFSTART	RF STRT FREQ	In frequency conversion mode, enter or query the measurement RF start frequency.
_RFSTOP	RF STOP FREQ	In frequency conversion mode, enter or query the measurement RF stop frequency.
_RL	REF LEVEL	Enter or query the reference level for the results display.
_RLPOS	REF LVL POSN	Enter or query the reference level position for the results display.
_SAVENR	SAVE ENR#	Enter or query the noise source serial number for saving ENR data.
_SAVLIM	SAVE LIMIT#	Enter or query the limit line number for saving limit line data.
_SLOSS	SOURCE LOSS	Enter or query the value of loss value affixed to the output of the noise source used in the measurement.
_TBW	T*BW PRODUCT	Enter or query the time-bandwidth product in MHz–seconds.
_TBWAUTO	AVG TIME AutoMan	Select or query the time-bandwidth mode. 1 indicates auto mode; 0 indicates manual mode.
_TEMPC	NS TEMP, DegC	Enter or query the noise source case temperature in °C.



## Command Syntax Description

Command syntax is represented pictorially as shown in Figure 6-1 below:



**Figure 6-1. Syntax Structure Description**

Descriptions of the syntax diagram symbols (or elements) are described below:

- Ovals enclose command mnemonics. The command mnemonic must be entered *exactly as shown* in diagrams.
- Circles and ovals surround secondary keywords or special numbers and characters. The characters in circles and ovals are considered reserved words and must be entered *exactly as shown* in diagrams.
- Rectangles surround the description of a syntax element. The element may be parameters, or variables, related to the command. The range of choices is listed in a table accompanying each command.

Syntax diagram elements are connected either with solid or dotted lines.

Solid-line paths represent *recommended* command paths. Combinations of elements generated by following the lines in the proper direction, creates syntactically correct commands.


---

## Command Reference

This section contains the alphabetical reference of the commands listed in Table 6-2. Each command description includes a syntax diagram, parameters as appropriate, and a description of the command function.

## \_AVGTIME

Use the \_AVGTIME command to enter an averaging time value.



xavgti . .

Figure 6-2. \_AVGTIME Syntax

Item	Description
Default Value	0.333 seconds
Default Units	s (seconds)
Range	0.1 sec to 1000 sec
Prerequisite Command	_NFMODE 1
Related Commands	_TBWAUTO, _TBW

### Description

When \_AVGTIME is set to automatic mode, the averaging time for measurements is automatically determined. The speed of the measurement affects the jitter, or repeatability, of the measurement. By increasing the averaging time, the measurement repeatability can be improved.

In automatic mode, the time-bandwidth product is divided by the measurement bandwidth to determine the averaging time per point.


In manual mode, just the measurement time is changed, the time-bandwidth value is not recalculated.

### Example

See Example 4, lines 150, 160.

### Query Response

The response is displayed in seconds.




qpts . .

Figure 6-3. \_AVGTIME Query Response Syntax

**\_AT**

Use the `_AT` command to enter an RF input attenuation value.



xgain1

**Figure 6-4. `_AT` Syntax**

Item	Description
<b>Default Value</b>	0 dB
<b>Default Units</b>	dB
<b>Range</b>	0 dB to maximum RF section attenuation
<b>Prerequisite Command</b>	<code>_NFMODE 1</code>
<b>Related Commands</b>	<code>_PREAMP</code>

**Description**


Use the `_AT` command to set the input attenuation of the RF section. When the preamp is enabled, an attenuation value of 0 will provide the best system noise figure. For devices under test that have high gain, the preamp can be disabled and the input attenuator should be set to prevent overloading of the input mixer in the RF section.

**Example**

See Example 4, lines 200, 210.

**Query Response**

The response is displayed in dB. To determine the actual attenuator setting, query the standard AT spectrum analyzer command instead of the `_AT` command.




qpts

**Figure 6-5. `_AT` Query Response Syntax**

## \_BEEP

Use the \_BEEP command to turn the end-of-measurement beeper ON or OFF



beep

Figure 6-6. \_BEEP Syntax


Item	Description
Default Value	1 (ON)
Default Units	none
Range	0 or 1
Prerequisite Command	_NFMODE 1
Related Commands	none

### Description

Use the \_BEEP command to turn the end-of-measurement beeper ON or OFF. The beeper is useful in notifying the operator that the measurement has completed. The beeper hardware is in the HP 70004A Display.

### Query Response

The response displays the beeper mode.




OFCONV

Figure 6-7. \_BEEP Query Response Syntax

## **\_BW**

The `_BW` command selects or queries the measurement resolution bandwidth.



xbw

**Figure 6-8. `_BW` Syntax**

Item	Description
<b>Default Value</b>	1.0 MHz
<b>Default Units</b>	Hz
<b>Range</b>	1.0 kHz to 3 MHz
<b>Prerequisite Command</b>	<code>_NFMODE 1</code>
<b>Related Commands</b>	<code>_TBWAUTO</code> , <code>_TBW</code>

### **Description**


The value of the `_BW` sets the measurement bandwidth. Changing the measurement resolution bandwidth when `_AVGTIME AUTO` is selected changes the averaging time. The new sweep time is the time-bandwidth product divided by the measurement bandwidth.

### **Example**

See Example 3, lines 120, 130.

## Query Response

The response is displayed in Hz.




qpts

**Figure 6-9. \_BW Query Response Syntax**

---

## **\_CAL**

The `_CAL` command initiates the system calibration routine.



xcal

**Figure 6-10. \_CAL Syntax**

Prerequisite Command: `_NFMODE 1`

### **Description**

Entering the `_CAL` command initiates the system calibration routine. The device under test is not connected. In addition, all measurement parameters (conversion, RF and IF frequencies, points, and so forth) must be entered prior to executing calibration.


### **Example**

See Example 3, lines 250-290.



## \_CONT

Use the \_CONT command to turn continuous measurement ON or OFF



cont

Figure 6-11. \_CONT Syntax


Item	Description
Default Value	1 (ON)
Default Units	none
Range	0 or 1
Prerequisite Command	_NFMODE 1
Related Commands	_PTS, _MNF, _MNFG, _MENR

### Description

Use the \_CONT command to turn the continuous measurement mode ON or OFF. In the continuous measurement mode, any measurement that is initiated will repeat until \_CONT 0 is sent to the analyzer. It is generally used only in the single-point mode, when \_PTS is set to 1.

### Query Response

The response displays the continuous measurement mode.



QFCONV

Figure 6-12. \_CONT Query Response Syntax

---

## **\_DEFAULTS**

Use the `_DEFAULTS` command to set the measurement parameters to a default state.



`defaults`

**Figure 6-13. \_DEFAULTS Syntax**

Prerequisite Command: `_NFMODE 1`

### **Description**

Entering the `_DEFAULTS` command sets the measurement parameters to a known default state. The default values are:

```
_AT 0DB  
_BEEP 1  
_BW 3MZ  
_CONT 0  
_FCONV 0  
_FSTART 100MZ  
_FSTOP 200MZ  
_IFSTART 1950MZ  
_IFSTOP 1450MZ  
_INLOSS 0DB  
_LIMITEST 0  
_LG 2  
_MSI 1  
_NFMODE 1  
_OUTLOSS 0  
_PLOTPTS 1  
_PREAMP 1  
_PTS 21  
_RFSTART 3.7E9  
_RFSTOP 4.2E9
```

## **`_DEFAULTS`**

```
_RL 0  
_RLPOS 0  
_SLOSS 0  
_TBW 1  
_TBWAUTO 1  
_TEMPC 17
```


### **Example**

See Example 4, line 80.

---

## **\_ENR**

\_ENR is used to query the measured DUT output Excess Noise Ratio trace data.



**Figure 6-14. \_ENR Syntax**


Item	Description
<b>Prerequisite Command</b>	none
<b>Related Commands</b>	_MENR

### **Description**

The \_ENR command is used to query the measured DUT output Excess Noise Ratio trace data. It must be preceded by the \_MENR command to have valid data in it.

### **Example**


Similar to \_NF command. See Example 4, lines 290, 320.



**Figure 6-15. \_ENR Query Response Syntax**

## \_FCONV

Use the \_FCONV command to select either frequency conversion mode or non-conversion mode.



fconv

Figure 6-16. \_FCONV Syntax

Item	Description
Default Value	0 (non-conversion)
Default Units	none
Range	0 or 1
Prerequisite Command	_NFMODE 1
Related Commands	_FSTART, _FSTOP, _RFSTART, _RFSTOP, _IFSTART, _IFSTOP

### Description

Use the \_FCONV command to select either frequency conversion or non-frequency conversion mode. When frequency conversion mode is selected, the specified RF start and stop frequencies are used to look up source ENR data, while the measurement is tuned to the IF frequencies during a measurement.


When non-frequency conversion mode is selected, the source ENR data corresponding to the measurement frequency is used.

### Example

See Example 4, line 100.

### Query Response

The response displays the frequency conversion mode.




oFCONV

Figure 6-17. \_FCONV Query Response Syntax

## **\_FSTART**

Use the `_FSTART` command to enter the start frequency for non-conversion mode measurements.



xfstar

**Figure 6-18. \_FSTART Syntax**

Item	Description
Default Value	100 MHz
Default Units	Hz
Range	Spectrum analyzer frequency range
Prerequisite Command	<code>_NFMODE 1</code>
Related Commands	<code>_FCONV</code> , <code>_FSTOP</code>

### **Description**


Use the `_FSTART` command for non-frequency conversion measurements. Enter or query the start frequency. The start frequency is typically the lowest frequency of the device under test.

### **Example**

See Example 3, line 100.

### **Query Response**

The response displays the start frequency value in Hz.




QFSTAR

**Figure 6-19. \_FSTART Query Response Syntax**

## \_FSTOP

Use the \_FSTOP command to enter the stop frequency for non-conversion mode measurements.



xfstop

Figure 6-20. \_FSTOP Syntax

Item	Description
<b>Default Value</b>	200 MHz
<b>Default Units</b>	Hz
<b>Range</b>	Spectrum analyzer frequency range
<b>Prerequisite Command</b>	_NFMODE 1
<b>Related Commands</b>	_FSTART, _FCONV

### Description


Use the \_FSTOP command for non-frequency conversion measurements. Enter or query the stop frequency. The stop frequency is typically the highest frequency of the device under test.

### Example

See Example 3, line 110.

### Query Response

The response displays the stop frequency value in Hz.



QFSTOP

Figure 6-21. \_FSTOP Query Response Syntax

## **\_FSTOP**

---

## **\_GAIN**

\_GAIN is used to query the measured DUT gain trace data.



gain

**Figure 6-22. \_GAIN Syntax**


<b>Item</b>	<b>Description</b>
<b>Prerequisite Command</b>	none
<b>Related Commands</b>	_MNFG

### **Description**

The \_GAIN command is used to query the measured DUT gain trace data. It must be preceded by the \_MNFG command to have valid data in it.

### **Example**

See Example 3, lines 650, 670.



QFSTAR

**Figure 6-23. \_GAIN Query Response Syntax**



## \_HI

\_HI is used to query the measured DUT output noise power trace data (noise source ON).




Figure 6-24. \_HI Syntax

Item	Description
Prerequisite Command	none
Related Commands	_CAL, _MENR, _MNF, _MNFG

### Description

The \_HI command is used to query the measured DUT output noise power trace data (while the noise source was ON). It must be preceded by the \_CAL, \_MENR, \_MNF, or \_MNFG command to have valid data in it.

### Example

See Example 3, lines 550,570.





Figure 6-25. \_HI Query Response Syntax

## **\_IFSTART**

Use the `_IFSTART` command to enter the IF start frequency for a frequency-conversion noise figure and gain measurement.



xifsta

**Figure 6-26. `_IFSTART` Syntax**

Item	Description
<b>Default Value</b>	1.95 GHz
<b>Default Units</b>	Hz
<b>Range</b>	Spectrum analyzer frequency range
<b>Prerequisite Command</b>	<code>_NFMODE 1</code>
<b>Related Commands</b>	<code>_FCONV</code> , <code>_RFSTART</code> , <code>_RFSTOP</code> , <code>_IFSTOP</code>

### **Description**

Use the `_IFSTART` command to set or query the IF start frequency value. The IF start and stop frequency spans must match the RF stop and start frequency span. Frequency conversion needs to be selected for these values to be active.


Reverse sweep, such as when the IF start frequency is greater than the IF stop frequency, is allowed.

### **Example**

See Example 4, line 110.

## Query Response

The response displays the current IF start frequency value.




`_IFSTART`

**Figure 6-27. \_IFSTART Query Response Syntax**

## \_IFSTOP

Use the \_IFSTOP command to enter the IF stop frequency for a frequency-conversion noise figure and gain measurement.



xifsto

Figure 6-28. \_IFSTOP Syntax

Item	Description
<b>Default Value</b>	1450 MHz
<b>Default Units</b>	Hz
<b>Range</b>	Spectrum analyzer frequency range
<b>Prerequisite Command</b>	_NFMODE 1
<b>Related Commands</b>	_FCONV, _RFSTART, _IFSTART, _RFSTOP

### Description


Use the \_IFSTOP command to set or query the IF stop frequency value. The IF start and stop frequency span must match the RF stop and start frequency span. The frequency conversion device under test determines the ranges of values. Frequency conversion needs to be selected for these values to be active.

### Example

See Example 3, line 120.

### Query Response

The response displays the current IF stop frequency value.



QIFSTO .

**Figure 6-29. \_IFSTOP Query Response Syntax**

---


## **\_INLOSS**

Use the `_INLOSS` command to correct for the dB loss values that exist at the input of the device under test.

---

**Note** If the loss is present when the calibration is made, do not enter a loss value with this command. These losses are introduced into the measurement setup after calibration is completed.

---



XINLOS


**Figure 6-30. \_INLOSS Syntax**

<b>Item</b>	<b>Description</b>
<b>Default Value</b>	0.0 dB
<b>Default Units</b>	dB
<b>Range</b>	-99.90 dB to +99.90 dB
<b>Prerequisite Command</b>	_NFMODE 1
<b>Related Commands</b>	_OUTLOSS, _SLOSS

## **Description**

Use the `_INLOSS` command to enter or query the dB loss value set for the input of the device under test, as illustrated in Figure 6-31. The loss value is based on cables and other loss factors that are in the measurement system.

Generally, a positive input-loss value is entered. A negative input-loss value indicates additional gain is present.



pa79a


**Figure 6-31. Location of Input Loss Characteristic**

**Example**

See Example 4, line 180.

**Query Response**

The response displays the current input loss value being used for measurement calculations.




QINLOS

**Figure 6-32. \_INLOSS Query Response Syntax**

## **\_LIMITEST**

Use the `_LIMITEST` command to turn the limit-line testing of noise figure results ON or OFF.



limitest .

**Figure 6-33. `_LIMITEST` Syntax**

Item	Description
<b>Default Value</b>	0 (OFF)
<b>Default Units</b>	none
<b>Range</b>	0 or 1
<b>Prerequisite Command</b>	<code>_NFMODE 1</code>
<b>Related Commands</b>	<code>LIMIFAIL</code> , <code>_LIMISAV</code> , <code>_LIMIRCL</code> , <code>_MSI</code>

### **Description**


The `_LIMITEST` command is used to turn the limit-line testing of noise figure results ON or OFF. The data in Trace A is compared to the limits in `L_5000` in internal memory. The `LIMIFAIL` command can be used to determine if the test is a PASS or a FAIL.

### **Example**

See Example 3, lines 750-810.

### **Query Response**

The response displays the limit test mode.




QFCONV .

**Figure 6-34. `_LIMITEST` Query Response Syntax**



## \_LG

Use the \_LG command to set the display scale for the measurement results.



xgains

Figure 6-35. \_LG Syntax

Item	Description
Default Value	10.0 dB
Default Units	dB
Range	0.1 dB to +20 dB
Prerequisite Command	_NFMODE 1
Related Commands	_RL

### Description


Use the \_LG command to set or query the scale for the results display. Changing the scale does not effect system calibration; therefore, it can be adjusted before or after the measurement.

### Example

See Example 3, line 340.

### Query Response

The response displays the current scale value.




OGAINS

Figure 6-36. \_LG Query Response Syntax

---

## **\_LOW**

Use `_LOW` to query the measured DUT output noise power trace data (noise source OFF).



**Figure 6-37. \_LOW Syntax**


Item	Description
<b>Prerequisite Command</b>	none
<b>Related Commands</b>	<code>_CAL</code> , <code>_MENR</code> , <code>_MNF</code> , <code>_MNFG</code>

### **Description**

The `_LOW` command is used to query the measured DUT output noise power trace data (while the noise source was OFF). It must be preceded by the `_CAL`, `_MENR`, `_MNF`, or `_MNFG` command to have valid data in it.

### **Example**

See Example 3, lines 580-600.




**Figure 6-38. \_LOW Query Response Syntax**

---

## **\_MENR**

Use the `_MENR` command to initiate the Excess Noise Ratio measurement sequence.



xmeas

**Figure 6-39. \_MENR Syntax**

Prerequisite Commands: `_NFMODE 1`, `_CAL`

### **Description**

Use the `_MENR` command to initiate a DUT output Excess Noise Ratio measurement. Before measurements can begin, the measurement configuration and system calibration (if an accurate ENR measurement is desired) must have been completed. Either accept the default configuration values, or refer to Table 6-2 for the list of commands available for setting measurement configuration.

The measurement results are located in the trace `_ENR`. The element 1 corresponds with the start frequency, and the element `N` corresponds with the stop frequency, where `N` equals the number of `_PTS`.

### **Description of Variables**

<b>Array or Variable Name</b>	<b>Description</b>	<b>Units =</b>
<code>_ENR</code>	The 800-point trace <code>_ENR</code> holds the output ENR measurement data.	dB


### **Example**

Similar to `_MNFG`. See Example 3, lines 220-300.

---

## MK\_RL

Use the MK\_RL command to set the results display reference level to the marker level.



mkrl

**Figure 6-40. MK\_RL Syntax**

Item	Description
<b>Prerequisite Command</b>	_NFMODE 1
<b>Related Commands</b>	MKN, MKPK, MKTRACE

### Description


The MK\_RL command is used to set the results display reference level to the marker level. When in the \_NFMODE 1 setting, use the MK\_RL command instead of the standard MKRL spectrum analyzer command.

### Example

See Example 3, line 400.

## \_MKTEMP

Use \_MKTEMP to calculate and query the marker noise temperature in °K.



mk temp

Figure 6-41. \_MKTEMP Syntax

Item	Description
Default Value	none
Default Units	none
Range	any integer
Prerequisite Command	_NFMODE 1
Related Commands	MKN, MKPK, MKTRACE


### Description

Use the \_MKTEMP command followed by any integer to perform a marker noise temperature calculation.

Then use the \_MKTEMP command to query the marker noise temperature in °K. A marker must be present on the noise figure trace (trace A) to use \_MKTEMP.

### Example

See Example 3, lines 470-500.




QFSTAR

Figure 6-42. \_MKTEMP Query Response Syntax

---

## **\_MNF**

Use the `_MNF` command to initiate the uncorrected noise figure measurement sequence.



mnf

**Figure 6-43. \_MNF Syntax**

Prerequisite Commands: `_NFMODE 1`

### **Description**

Use the `_MNF` command to initiate an uncorrected noise figure measurement. An uncorrected noise figure measurement does not remove the contribution of the measurement system (preamp + spectrum analyzer) noise figure from the result. Before measurements can begin, the measurement configuration must have been completed. Because no second stage correction is made, `_CAL` is not necessary. Either accept the default configuration values, or refer to Table 6-2 for the list of commands available for setting measurement configuration.

The measurement results are located in the trace `_NF`. The element 1 corresponds with the start frequency, and the element `N` corresponds with the stop frequency, where `N` equals the number of `_PTS`.

### **Description of Variables**


<b>Array or Variable Name</b>	<b>Description</b>	<b>Units =</b>
<code>_NF</code>	The 800-point trace <code>_NF</code> holds the noise figure measurement data.	dB

### **Example**

See Example 4, lines 240-270.

## \_MNFG

Use the \_MNFG command to initiate the corrected noise figure and gain measurement sequence.



mnfg

**Figure 6-44. \_MNFG Syntax**

Prerequisite Commands: \_NFMODE 1, \_CAL

### Description

Use the \_MNFG command to initiate a corrected noise figure and gain measurement. Before measurements can begin, the measurement configuration and system calibration (if an accurate noise figure measurement or a gain trace is desired) must have been completed. Either accept the default configuration values, or refer to Table 6-2 for the list of commands available for setting measurement configuration.

The measurement results are located in the traces \_NF and \_GAIN. The element 1 corresponds with the start frequency, and the element N corresponds with the stop frequency, where N equals the number of \_PTS.

### Description of Variables


Array or Variable Name	Description	Units =
_NF	The 800-point trace _NF holds the noise figure measurement data.	dB
_GAIN	The 800-point trace _GAIN holds the gain measurement data.	dB.

### Example

See Example 3, lines 220-300.

## **\_MSI**

Use the \_MSI command to select the location for storing or retrieving files.



ms i

**Figure 6-45. \_MSI Syntax**

Item	Description
<b>Default Value</b>	1 (MSIB)
<b>Default Units</b>	none
<b>Range</b>	0 or 1
<b>Prerequisite Command</b>	none
<b>Related Commands</b>	_LIMISAV, _LIMIRCL, _SAVENR, _RCLENR

### **Description**


The \_MSI command is used to select location for storing or retrieving files. A value of 0 selects INTERNAL memory. A value of 1 selects MSIB (memory card). \_MSI performs a function similar to the standard MSI command, but should be used instead of MSI for storing and retrieving limit lines and ENR tables that will be used by the noise figure measurement personality.

### **Example**

See Example 1, lines 170,210, Example 2, lines 190,230, and Example 3, lines 190,760,

### **Query Response**

The response displays the mass storage setting.



QF CONV

**Figure 6-46. \_MSI Query Response Syntax**



## \_NF

Use \_NF to query the measured DUT noise figure trace data.




Figure 6-47. \_NF Syntax

Item	Description
Prerequisite Command	none
Related Commands	_MNF, _MNFG

### Description

The \_NF command is used to query the measured DUT noise figure trace data. It must be preceded by the \_MNF, or \_MNFG command to have valid data in it.

### Example

See Example 3, lines 620-640 and lines 680-730





Figure 6-48. \_NF Query Response Syntax

## **\_NFMODE**

Use the `_NFMODE` command to enable or disable the noise figure measurement mode.



n.fmode

**Figure 6-49. \_NFMODE Syntax**

Item	Description
<b>Default Units</b>	none
<b>Range</b>	0 or 1
<b>Prerequisite Command</b>	none
<b>Related Commands</b>	most NF measurement commands

### **Description**

The `_NFMODE` command is used to enable or disable the noise figure measurement mode. `_NFMODE 1` is used to enable the noise figure measurement mode. `_NFMODE 0` is used to disable the noise figure measurement mode and return to normal spectrum analyzer operation. Most of the commands in the noise figure measurement personality must be preceded by a `_NFMODE 1` command to work correctly.


Note that if the analyzer is already in the noise figure measurement mode, subsequent `_NFMODE 1` commands will be ignored. Likewise, if the analyzer is in its normal spectrum analyzer mode, subsequent `_NFMODE 0` commands will be ignored.

### **Example**

See Example 3, line 70 , Example 4, lines 70,350

### **Query Response**

The response displays the noise figure measurement mode.




QFCONV

**Figure 6-50. \_NFMODE Query Response Syntax**

## \_NFSA

Use \_NFSA to query the measured system noise figure trace data.



nfsa

Figure 6-51. \_NFSA Syntax


Item	Description
Prerequisite Command	none
Related Commands	_CAL, _MENR, _MNFG

### Description

The \_NFSA command is used to query the measured system (preamp + spectrum analyzer noise figure trace data. It must be preceded by the \_CAL command to have valid data in it.

### Example

Similar to \_NF. See Example 3, lines 620-640.



QFSTAR

Figure 6-52. \_NFSA Query Response Syntax

---


## **\_OUTLOSS**

Use the `_OUTLOSS` command to correct for the dB loss value that exists at the output of the device under test, before the input to the system preamplifier.

---

**Note** If the loss is present when the calibration is made, do not enter a loss value with this command. These losses are introduced into the measurement setup after calibration is completed.

---



XOUTLO


**Figure 6-53. \_OUTLOSS Syntax**

Item	Description
<b>Default Value</b>	0.00 dB
<b>Default Units</b>	dB
<b>Range</b>	-99.90 to +99.90 dB
<b>Prerequisite Command</b>	<code>_NFMODE 1</code>
<b>Related Commands</b>	<code>_INLOSS</code> , <code>_SLOSS</code>

### **Description**

Use the `_OUTLOSS` command to enter or query the dB loss value set for the output of the device under test, as illustrated in Figure 6-54. The loss value is due to cables and other loss factors that are required in the measurement system.

Generally, a positive output-loss value is entered. A negative output-loss value indicates additional gain is present.



pa710a


Figure 6-54. Location of Output Loss Characteristic

**Example**

See Example 3, line 190.

**Query Response**

The response displays the current output loss value being used for measurement calculations.




00UTLO

Figure 6-55. \_OUTLOSS Query Response Syntax

## **\_PLOTPTS**

Use the `_PLOTPTS` command to enable or disable results plotting on display.



`plotpts`

**Figure 6-56. `_PLOTPTS` Syntax**

Item	Description
<b>Default Value</b>	1 (ON)
<b>Default Units</b>	none
<b>Range</b>	0 or 1
<b>Prerequisite Command</b>	<code>_NFMODE 1</code>
<b>Related Commands</b>	<code>_CAL</code> , <code>_MENR</code> , <code>_MFN</code> , <code>_MNFG</code>

### **Description**

The `_PLOTPTS` command is used to enable or disable the transfer of measurement results to Trace A and Trace B for display. `_PLOTPTS 1` is used to enable results plotting to the display. `_PLOTPTS 0` is used to disable results plotting to the display.


`_PLOTPTS 0` is useful when the spectrum analyzer is being driven by a remote computer, to reduce overall measurement time if display is not needed. Note that with `_PLOTPTS 0`, Trace A and Trace B do not contain valid measurement results.

### **Example**

See Example 4, line 220

### **Query Response**

The response displays the measurement results display mode.




`QFCNV`

**Figure 6-57. `_PLOTPTS` Query Response Syntax**

## \_PREAMP

Use the \_PREAMP command to enable or disable the internal preamp.



preamp

Figure 6-58. \_PREAMP Syntax

Item	Description
Default Value	1 (enabled)
Default Units	none
Range	0 or 1
Prerequisite Command	_NFMODE 1
Related Commands	_CAL, _MENR, _MFN, _MNFG

### Description

The \_PREAMP command is used to enable or disable the internal preamplifier (HP 70620B or HP 70621A). \_PREAMP 1 is used to enable the preamp. \_PLOTPTS 0 is used to disable (bypass) the preamp.


\_PREAMP 0 is useful in testing high gain devices whose output noise would overload the internal preamp. In this case, \_CAL may not work well due to the relatively high noise figure of the spectrum analyzer, but the \_MNF uncorrected noise figure measurement could still be made.

### Example

See Example 4, lines 240-270

### Query Response

The response displays the internal preamp mode.




OFCONV

Figure 6-59. \_PREAMP Query Response Syntax

## **\_PTS**

Use the `_PTS` command to select the number of measurement points.



xpts

**Figure 6-60. \_PTS Syntax**

Item	Description
<b>Default Value</b>	21
<b>Default Units</b>	none
<b>Range</b>	1 to 800
<b>Prerequisite Command</b>	<code>_NFMODE 1</code>
<b>Related Commands</b>	<code>_FSTART</code> , <code>_FSTOP</code> , <code>_IFSTART</code> , <code>_IFSTOP</code> , <code>_RFSTART</code> , <code>_RFSTOP</code>

## **Description**

Use the `_PTS` command to set or query the number of measurement points.

The number of measurement points determines number of equally spaced frequency points evaluated for noise figure and gain. If the number of points is set to 1, measurement results will be displayed as text. If the number is greater than 1, the results will be displayed as a graph.


Number Entered	Actual Number Points Measured
1	1 point
2	1 point
$3 \leq N \leq 800$	N points
$N > 800$	800 points

## **Example**

See Example 3, line 90 or Example 4, line 90

## **Query Response**

The response displays the current number of points selected.




qpts

**Figure 6-61. \_PTS Query Response Syntax**



## \_RCLLENR

Use the \_RCLLENR command to recall and use a noise source ENR table in measurements.



rcllenr

Figure 6-62. \_RCLLENR Syntax

Item	Description
Default Value	1
Default Units	none
Range	1 to 4999
Prerequisite Command	_NFMODE 1
Related Commands	_MSI, _SAVENR

### Description

An ENR table can be recalled from an existing table stored in the internal memory or from a table stored on a memory card, depending on the setting of \_MSI. The recalled table is then applied in all subsequent measurements.


**Note** The noise figure measurement personality always uses the table stored in the L0 limit line file in internal memory to perform calculations of noise figure and gain. The purpose of the \_RCLLENR command is to copy the contents of the specified file (either in internal memory or externally on a memory card) into the L0 limit line file in internal memory.

### Example

See Example 3, lines 180-200

### Query Response

The response displays the file number that the noise source ENR table is recalled from.




QOUTLO

Figure 6-63. \_RCLLENR Query Response Syntax

---

## **\_RCLLIM**

Use the `_RCLLIM` command to recall and use a limit line table for comparing against results.



rcllim

**Figure 6-64. \_RCLLIM Syntax**

Item	Description
<b>Default Value</b>	1
<b>Default Units</b>	none
<b>Range</b>	1 to 4999
<b>Prerequisite Command</b>	<code>_NFMODE 1</code>
<b>Related Commands</b>	<code>_LIMITEST</code> , <code>_MSI</code> , <code>_SAVLIM</code>

### **Description**

A limit line table can be recalled from an existing table stored in the internal memory or from a table stored on a memory card, depending on the setting of `_MSI`. The recalled table is then used to compare against the measurement results with the `_LIMITEST` command.

---

**Note** The noise figure measurement personality always uses the table stored in the `L5000` limit line file in internal memory to perform limit line comparisons against the measured results. The purpose of the `_RCLLIM` command is to copy the contents of the specified file (either in internal memory or externally on a memory card) into the `L5000` limit line file in internal memory.


---

### **Example**

See Example 3, lines 750-810

### **Query Response**

The response displays the file number that the limit line table is recalled from.




QOUTLO

**Figure 6-65. \_RCLLIM Query Response Syntax**

## **\_REVNFG**

Use `_REVNFG` to query the Noise Figure and Gain software revision date.



revnfg .

**Figure 6-66. \_REVNFG Syntax**


<b>Item</b>	<b>Description</b>
<b>Prerequisite Command</b>	none
<b>Related Commands</b>	none

### **Description**

The `_REVNFG` command is used to query the software revision date of the Noise Figure and Gain personality software.

### **Query Response**

The response displays the revision date in year/month/date sequence.




QFSTAR .

**Figure 6-67. \_REVNFG Query Response Syntax**

## **\_RFSTART**

Use the `_RFSTART` command to enter the RF start frequency for a frequency-conversion noise figure and gain measurement.



xrfsta

**Figure 6-68. \_RFSTART Syntax**

Item	Description
<b>Default Value</b>	3.70 GHz
<b>Default Units</b>	Hz
<b>Range</b>	0.0 Hz to 1E26 Hz
<b>Prerequisite Command</b>	<code>_NFMODE 1</code>
<b>Related Commands</b>	<code>_FCONV</code> , <code>_IFSTART</code> , <code>_IFSTOP</code> , <code>_RFSTOP</code>

### **Description**


Use the `_RFSTART` command to set or query the RF start frequency value. The RF start and stop frequency span must match the IF stop and start frequency span. Frequency conversion needs to be selected for these values to be active.

### **Example**

See Example 4, line 130.

### Query Response

The response displays the current RF start frequency value.




ORFSTA

**Figure 6-69. \_RFSTART Query Response Syntax**

## **\_RFSTOP**

Use the \_RFSTOP command to enter the RF stop frequency for a frequency-conversion noise figure and gain measurement.



xrfsto .

**Figure 6-70. \_RFSTOP Syntax**

Item	Description
<b>Default Value</b>	4.20 GHz
<b>Default Units</b>	Hz
<b>Range</b>	0.0 Hz to 1E26 Hz
<b>Prerequisite Command</b>	_NFMODE 1
<b>Related Commands</b>	_FCONV, _IFSTART, _IFSTOP, _RFSTART

### **Description**


Use the \_RFSTOP command to set or query the RF stop frequency value. The RF start and stop frequency span must match the IF stop and start frequency span. Frequency conversion needs to be selected for these values to be active.

### **Example**

See Example 4, line 140.

### Query Response

The response displays the current RF stop frequency value.




ORFSTO

**Figure 6-71. \_RFSTOP Query Response Syntax**

---

## **\_RL**

Use the `_RL` command to set the display reference level for the measurement results.



**Figure 6-72. \_RL Syntax**

Item	Description
<b>Default Value</b>	0 dB
<b>Default Units</b>	dB
<b>Range</b>	-300 dB to +300 dB
<b>Prerequisite Command</b>	<code>_NFMODE 1</code>
<b>Related Commands</b>	<code>_LG</code> , <code>_RLPOS</code>

### **Description**


Use the `_RL` command to set or query the reference level for the results display. Changing the reference level does not effect system calibration; therefore, it can be adjusted before or after the measurement.

### **Example**

See Example 3, line 330.

### **Query Response**

The response displays the current display reference level value.




**Figure 6-73. \_RL Query Response Syntax**



## \_RLPOS

Use the \_RLPOS command to set the display reference level position for the measurement results.



r l pos

Figure 6-74. \_RLPOS Syntax

Item	Description
Default Value	0
Default Units	none
Range	0 to 10
Prerequisite Command	_NFMODE 1
Related Commands	_LG, _RL

### Description


Use the \_RLPOS command to set or query the reference level position for the results display. There are eleven reference level positions on the display, starting with 0 at the bottom and ending with 10 at the top. Changing the reference level position does not effect system calibration; therefore, it can be adjusted before or after the measurement.

### Example

See Example 3, line 350.

### Query Response

The response displays the current display reference level position value.




QGA I NS

Figure 6-75. \_RLPOS Query Response Syntax

---

## **\_SAVENR**

Use the `_SAVENR` command to save a noise source ENR table in internal or external memory.



SAVENR

**Figure 6-76. \_SAVENR Syntax**

Item	Description
<b>Default Value</b>	1
<b>Default Units</b>	none
<b>Range</b>	1 to 4999
<b>Prerequisite Command</b>	<code>_NFMODE 1</code>
<b>Related Commands</b>	<code>_MSI</code> , <code>_RCLENR</code>

### **Description**

The `_SAVENR` command is used to save the noise source ENR table presently in use into internal memory or a memory card, depending on the setting of `_MSI`.

---

**Note** The noise figure measurement personality always uses the table stored in the `L0` limit line file in internal memory to perform calculations of noise figure and gain. The purpose of the `_SAVENR` command is to copy the contents of the `L0` limit line file to the specified file (either in internal memory or externally on a memory card).


---

### **Example**

See Example 1, lines 200-220

### **Query Response**

The response displays the file number that the noise source ENR table is will be saved to.




OUTLO

**Figure 6-77. \_SAVENR Query Response Syntax**

## \_SAVLIM

Use the \_SAVLIM command to save a limit line table in internal or external memory.



save lim

Figure 6-78. \_SAVLIM Syntax

Item	Description
<b>Default Value</b>	1
<b>Default Units</b>	none
<b>Range</b>	1 to 4999
<b>Prerequisite Command</b>	_NFMODE 1
<b>Related Commands</b>	_LIMITEST, _MSI, _RCLLIM

### Description

A limit line table presently being used by the noise figure personality can be saved to internal memory or an external memory card, depending on the setting of \_MSI.


**Note** The noise figure measurement personality always uses the table stored in the L5000 limit line file in internal memory to perform limit line comparisons against the measured results. The purpose of the \_SAVLIM command is to copy the contents of the L5000 limit line file to the specified file (either in internal memory or externally on a memory card).

### Example

See Example 2, lines 220-240

### Query Response

The response displays the file number that the limit line table is saved to.




OUTLO

Figure 6-79. \_SAVLIM Query Response Syntax

## \_SLOSS

Use the \_SLOSS command to correct for the dB loss values that exist between the input of the device under test and the noise source.

This loss exists during the calibration procedure and during the measurement.




XSLOSS

Figure 6-80. \_SLOSS Syntax

Item	Description
Default Value	0.00 dB
Default Units	dB
Range	-99.90 to +99.90 dB
Prerequisite Command	_NFMODE 1
Related Commands	_INLOSS, _OUTLOSS

## Description

Use the \_SLOSS command to enter or query the dB loss value located at the noise source used in the measurement system, as illustrated in Figure 6-81. The loss value is based on cables and other loss factors that are required in the measurement system.



pa78a


Figure 6-81. Location of Noise Source Loss Characteristic

**Example**

See Example 4, line 190

**Query Response**

The response displays the current output loss value being used for measurement calculations.




QSLOSS

**Figure 6-82. \_SLOSS Query Response Syntax**

## **\_TBW**

Use the `_TBW` command to enter the time bandwidth product for use in measurements.



XTBW

**Figure 6-83. \_TBW Syntax**

Item	Description
<b>Default Value</b>	1 MHz-s
<b>Default Units</b>	MHz-s
<b>Range</b>	0.0001 to 3,000 MHz-s
<b>Prerequisite Command</b>	<code>_NFMODE 1</code>
<b>Related Commands</b>	<code>_TBWAUTO</code> , <code>_BW</code>


### **Description**

Use the `_TBW` command to enter or query the time-bandwidth product. The time-bandwidth product is used to calculate an averaging time appropriate for a given measurement bandwidth when TBW AUTO mode is selected. Refer to the `_TBWAUTO` command.

The time-bandwidth product affects the measurement-to-measurement repeatability. An increase in time-bandwidth reduces the repeatability error.

### **Query Response**

The response displays the time-bandwidth product used when auto mode is selected.




QTBW

**Figure 6-84. \_TBW Query Response Syntax**

## \_TBWAUTO

Use the \_TBWAUTO command to select either automatic or manual time-bandwidth mode for use in measurements.



xtbwau

Figure 6-85. \_TBWAUTO Syntax


Item	Description
Default Value	1 (ON)
Default Units	none
Range	1 (ON) or 0 (OFF)
Prerequisite Command	_NFMODE 1
Related Commands	_TBW, _BW, _AVGTIME

### Description

Use the \_TBWAUTO command to enter or query the measurement time-bandwidth mode. The automatic time-bandwidth mode provides an automatically calculated averaging time. The calculations are derived from the time-bandwidth product divided by the measurement bandwidth.

### Query Response

The response displays the current time-bandwidth measurement mode. If a 1 is returned, the mode is automatic. If a 0 is returned, the mode is manual and the measurement time and bandwidth settings are determined by you.




QTBWAU

Figure 6-86. \_TBWAUTO Query Response Syntax

## **\_TEMPC**

Use the `_TEMPC` command to enter the celsius case-temperature value of the noise source used for making measurements.



x tempc

**Figure 6-87. \_TEMPC Syntax**


Item	Description
<b>Default Value</b>	17°C
<b>Default Units</b>	°C
<b>Range</b>	0.0° to 1000°C
<b>Prerequisite Command</b>	_NFMODE 1
<b>Related Commands</b>	none

## **Description**

Use the `_TEMPC` command to enter or query the case temperature of the noise source being used for measurements. The case temperature is determined by the temperature of the environment where the measurements are being made.

## **Query Response**

The response displays the current temperature selected.



QTEMPC

**Figure 6-88. \_TEMPC Query Response Syntax**



---

## Example Programs

### Creating and Saving Noise Source ENR Tables

```
10  !
20  ! EXAMPLE 1
30  !
40  ! This example demonstrates the creation and saving of Noise Source ENR tables.
50  !
60  ! Create a new noise source ENR table:
70  OUTPUT 718;"LIMIDEL;"          ! Erase contents of limit line table.
80  OUTPUT 718;"LIMILINE 5;"      ! ENR table will contain 5 points.
90  OUTPUT 718;"LIMIHAF UPPE;"    ! ENR tables only use upper limit line.
100 OUTPUT 718;"LIMISEG 1E7,13.25,SLOPE;"! First point: freq=10MHZ,ENR=13.25dB
110 OUTPUT 718;"LIMISEG 5E9,13.61,SLOPE;"! Next point: freq=5GHz, ENR=13.61dB
120 OUTPUT 718;"LIMISEG 1E10,14.78,SLOPE;"! Next point: freq=10GHz,ENR=14.78dB
130 OUTPUT 718;"LIMISEG 15E9,15.23,SLOPE;"! Next point: freq=15GHz,ENR=15.23dB
140 OUTPUT 718;"LIMISEG 20E9,15.27,SLOPE;"! Last point: freq=20GHz,ENR=15.27dB
150 OUTPUT 718;"LIMITEST OFF;"    ! Turn limit test OFF.
160 OUTPUT 718;"LIMIDONE;"        ! Finish limit line table editing.
170 OUTPUT 718;"_MSI 0;"          ! Select internal memory for saving.
180 OUTPUT 718;"LIMISAV 0;"      ! Save ENR table in limit line 0 (NF personality looks for
                                source ENR table here).
190 !
200 ! Save noise source ENR table in external memory card:
210 OUTPUT 718;"_MSI 1;"          ! Select external memory card.
220 OUTPUT 718;"_SAVENR 4999;"    ! Save ENR table as l_4999 on memory card.
230 END
```

## Creating and Saving Limit Line Tables

```
10  !
20  ! EXAMPLE 2
30  !
40  ! This example demonstrates the creation and saving of limit line tables.
50  !
60  ! Create a limit line table:
70  OUTPUT 718;"LIMIDEL;"          ! Erase contents of limit line table.
80  OUTPUT 718;"LIMILINE 3;"      ! Limit line table will contain 3 points.
90  OUTPUT 718;"LIMIHAF UPPE;"    ! Edit upper limit line.
100 OUTPUT 718;"LIMISEG 1E7,4.0,SLOPE;" ! First point: freq=10MHZ, 4.0dB
110 OUTPUT 718;"LIMISEG 5E9,5.0,SLOPE;" ! Next point: freq=5GHz, 5.0dB
120 OUTPUT 718;"LIMISEG 20E9,7.0,SLOPE;" ! Last point: freq=20GHz, 7.0dB
130 OUTPUT 718;"LIMIHAF LOWER;"   ! Edit lower limit line.
140 OUTPUT 718;"LIMISEG 1E7,2.0,SLOPE;" ! First point: freq=10MHZ, 2.0dB
150 OUTPUT 718;"LIMISEG 5E9,1.0,SLOPE;" ! Next point: freq=5GHz, 1.0dB
160 OUTPUT 718;"LIMISEG 20E9,0.0,SLOPE;" ! Last point: freq=20GHz, 0.0dB
170 OUTPUT 718;"LIMITEST OFF;"    ! Turn limit test OFF.
180 OUTPUT 718;"LIMIDONE;"        ! Finish limit line table editing.
190 OUTPUT 718;"_MSI 0;"          ! Select internal memory for saving.
200 OUTPUT 718;"LIMISAV 5000;"    ! Save limit line in l_5000 in internal memory
                                   (NF personality looks for limit line table in l_5000).

210  !
220  ! Save limit line table in external memory card:
230  OUTPUT 718;"_MSI 1;"         ! Select external memory card.
240  OUTPUT 718;"_SAVLIM 4999;"   ! Save limit line table as l_9999 (value+5000) on memory
                                   card.

250  END
```

## Corrected Non-Conversion Noise Figure and Gain Measurements

```
10  !
20  ! EXAMPLE 3
30  !
40  ! This example demonstrates corrected non-conversion noise figure and gain measurement.
50  !
60  ! Set-up Noise Figure Measurement configuration:
70  OUTPUT 718; "_NFMODE 1;"          ! Select NF Measurements mode.
80  OUTPUT 718; "_DEFAULTS;"        ! Set all measurement configuration parameters to default
                                     values.
90  OUTPUT 718; "_PTS 11;"          ! Set the number of measurement points to 11.
100 OUTPUT 718; "_FSTART 1.2GZ;"    ! Set the non-conversion mode start frequency to 1.2 GHz.
110 OUTPUT 718; "_FSTOP 2.5GZ;"    ! Set the non-conversion mode stop frequency to 2.5 GHz.
120 OUTPUT 718; "_BW 1MZ;"         ! Set the resolution bandwidth to 1 MHz.
130 OUTPUT 718; "_TBW 0.5;"        ! Set the time*bandwidth product to 0.5 MHz-Sec.
140 OUTPUT 718; "_TEMPC 19;"       ! Enter the case temperature of the noise source as 19
                                     degrees C.
150 OUTPUT 718; "DONE?;"          ! Query Spectrum Analyser for the calibration routine
                                     status.
160 ENTER 718; Done                ! Get the status condition.
170  !
180 ! Recall a noise source ENR table from the external memory card:
190 OUTPUT 718; "_MSI 1;"          ! Select the external memory card.
200 OUTPUT 718; "_RCLENR 4999;"    ! Recall the ENR table saved in 1_4999 on the memory card.
210  !
220 ! Make a corrected noise figure and gain measurement:
230 DISP "CALIBRATION - CONNECT NOISE SOURCE OUTPUT TO PREAMP INPUT, THEN PRESS CONTINUE."
240 PAUSE
250 OUTPUT 718; "_CAL;"            ! Initiate the system calibration.
260 OUTPUT 718; "DONE?;"          ! Query Spectrum Analyser for the calibration routine
                                     status.
270 ENTER 718; Done                ! Get the status condition.
280 DISP "CALIBRATION DONE, CONNECT DUT BETWEEN NOISE SOURCE OUTPUT AND PREAMP INPUT, PRESS
CONTINUE."
290 PAUSE
300 OUTPUT 718; "_MNFG;"          ! Initiate noise figure and gain measurement.
310  !
320 ! Adjust the display for viewing traces:
330 OUTPUT 718; "_RL 1DBM;"        ! Adjust display reference level to 1 dB.
340 OUTPUT 718; "_LG 1DB;"        ! Adjust display scale to 1 dB/div.
350 OUTPUT 718; "_RLPOS 5;"       ! Set reference level position to 5th division from
                                     bottom of screen.
360  !
370 ! Place a marker on the noise figure trace and read it.
380 OUTPUT 718; "MKTRACE TRA;"    ! Place marker on trace A (noise figure trace)
390 OUTPUT 718; "MKPK;"          ! Place marker at peak of noise figure trace.
400 OUTPUT 718; "MK_RL;"         ! Set reference level to marker amplitude.
410 OUTPUT 718; "MKA?;"          ! Query marker amplitude.
420 ENTER 718; A                  ! Read value.
430 PRINT "Peak Noise Figure=", A
440 OUTPUT 718; "MKF?"           ! Query marker frequency.
450 ENTER 718; A                  ! Read value.
460 PRINT "Frequency=", A, "Hz"
470 OUTPUT 718; "_MKTEMP 0;"      ! Calculate marker noise temperature.
480 OUTPUT 718; "_MKTEMP?;"      ! Query marker noise temperature.
490 ENTER 718; A                  ! Read value.
500 PRINT "Noise Temperature=", A, "degrees K"
510  !
520 ! Query output data:
530 OUTPUT 718; "_SENr[1]?;"      ! Query noise source ENR first point.
540 ENTER 718; Senr              ! Read data value.
550 PRINT "Noise Source ENR=", Senr
560 OUTPUT 718; "_HI[1]?;"       ! Query DUT output noise first point.
570 ENTER 718; Hi                ! Read data value.
```

```

580 PRINT "DUT Output Noise (Source ON)=",Hi
590 OUTPUT 718;"_LOW[1]?;"          ! Query DUT output noise first point.
600 ENTER 718;Low                   ! Read data value.
610 PRINT "DUT Output Noise (Source OFF)=",Low
620 OUTPUT 718;"_NF[1]?;"          ! Query measured Noise Figure first point.
630 ENTER 718;Nf                    ! Read data value.
640 PRINT "DUT Noise Figure=",Nf
650 OUTPUT 718;"_GAIN[1]?;"        ! Query measured DUT Gain first point.
660 ENTER 718;Gain                  ! Read data value.
670 PRINT "DUT Gain=",Gain
680 DIM Nftrace(1:800)              ! Dimension an 800 point array to hold the NF trace.
690 OUTPUT 718;"_NF?;"              ! Query measured Noise Figure entire trace.
700 ENTER 718;Nftrace(*)           ! Read trace data.
710 FOR N=1 TO 11                   ! Print the first 11 points.
720 PRINT "Point",N,"NF=",Nftrace(N)
730 NEXT N
740 !
750 ! Turn limit line checking ON and read PASS/FAIL:
760 OUTPUT 718;"_MSI 1;"            ! Select external memory card.
770 OUTPUT 718;"_RCLLIM 4999;"      ! Recall limit line l_9999 on memory card.
780 OUTPUT 718;"_LIMITEST 1;"      ! Turn limit test function ON.
790 OUTPUT 718;"LIMIFAIL?;"        ! Query limit line test results.
800 ENTER 718;A                     ! Read data.
810 PRINT "FAIL?",A
820 END

```

## Frequency Conversion Measurement Mode

```
10  !
20  ! EXAMPLE 4
30  !
40  ! This example displays the frequency conversion measurement mode, and the use of external
    ! loss corrections.
50  !
60  ! Set-up Noise Figure Measurement configuration:
70  OUTPUT 718;"_NFMODE 1;"          ! Select NF Measurements mode.
80  OUTPUT 718;"_DEFAULTS;"        ! Set all measurement configuration parameters to default
    ! values.
90  OUTPUT 718;"_PTS 25;"          ! Set the number of measurement points to 25.
100 OUTPUT 718;"_FCONV 1;"         ! Turn frequency conversion mode ON.
110 OUTPUT 718;"_IFSTART 400MZ;"   ! Set the frequency conversion measurement IF start
    ! frequency to 400 MHz.
120 OUTPUT 718;"_IFSTOP 600MZ;"   ! Set the frequency conversion measurement stop frequency
    ! to 600 MHz.
130 OUTPUT 718;"_RFSTART 650MZ;"  ! Set the conversion measurement RF start frequency to
    ! 650 MHz.
140 OUTPUT 718;"_RFSTOP 850MZ;"   ! Set the conversion measurement RF stop frequency to
    ! 850 MHz, which results in a span equal to the IF span
    ! of 200 MHz
150 OUTPUT 718;"_TBWAUTO 0;"      ! Set the averaging time mode to manual.
160 OUTPUT 718;"_AVGTIME 1S;"     ! Set the averaging time to 1 second per measurement point.
170 OUTPUT 718;"_SLOSS 0.1DB;"    ! Enter the 0.1 dB loss that exists in the setup, during
    ! calibration and measurement, at the noise source output.
180 OUTPUT 718;"_INLOSS 1DB;"     ! Enter the 1 dB loss that exists in the measurement
    ! setup, following calibration, and is present at the
    ! DUT input.
190 OUTPUT 718;"_OUTLOSS 2 DB;"   ! Enter the 2 dB loss that exists in the measurement
    ! setup, following calibration, and is present at the
    ! DUT output.
200 OUTPUT 718;"_AT 10DB;"        ! Set RF section input attenuation to 10 dB during
    ! measurements.
210 OUTPUT 718;"_PREAMP 0;"       ! Turn internal preamp OFF.
220 OUTPUT 718;"_PLOTPTS 0;"      ! Turn results display OFF for faster remote operation.
230  !
240 ! Make an uncorrected noise figure measurement:
250 OUTPUT 718;"_MNF;"            ! Initiate uncorrected noise figure measurement.
260 OUTPUT 718;"DONE?;"          ! Query Spectrum Analyzer for the measurement status.
270 ENTER 718;Done                ! Get the status condition.
280  !
290 ! Query Measured Noise Figure Data:
300 OUTPUT 718;"_NF[1]?;"        ! Query measured Noise Figure data.
310 ENTER 718;A                   ! Read data value.
320 PRINT "Noise Figure=",A
330  !
340 ! Exit Noise Figure Measurement Mode:
350 OUTPUT 718;"_NFMODE 0;"      ! Exit NF measurement mode.
360  END
```



# Index

---

## A

ABORT, 3-9  
accuracy, measurement, 2-2  
additional equipment, 2-3  
adjustments, display, 2-24  
amplifier measurements, 2-17  
amplifier output ENR measurements, 2-19  
AMPTD VALUE, 3-9  
ATTEN, 3-9  
attenuation, adjusting, 2-11  
averaging, 2-5  
AVG TIME, 3-9

## B

bandwidth, entering, 2-5  
BEEPER On Off, 3-9

## C

CAL, 3-10  
calibrating for ENR, 4-5  
calibration, 2-15  
    power meter, 4-5  
    spectrum analyzer, 4-5  
caution  
    caution symbol, vi  
characteristics, 4-2  
command description, 6-13  
commands  
    alphabetical listing, 6-12  
    programming, 6-1  
command syntax description, 6-11  
configuration  
    default, 2-3  
    measurement, 2-3  
CONT TEST, 3-10  
conventions, key, 1-1

## D

default configuration, 2-3  
DEFAULT STATE, 3-10  
DEFAULT TEST, 3-11  
DELETE POINT, 3-11  
deleting DLP, 1-2  
DELTA, 3-11  
delta markers, 2-25  
disabling internal preamp, 2-11

display, adjusting, 2-24  
display markers, 2-25  
disposing DLP, 1-2  
DLP VERSION, 3-11

## E

EDIT DONE, 3-11  
editing  
    ENR data, 2-12  
    limit lines, 2-27  
EditSrc ENR, 3-11  
enabling internal preamp, 2-11  
ENR, amplifier output, 2-19  
ENR calibration, 4-5  
ENR, editing data, 2-12  
ENR, recalling data, 2-13  
ENR, saving data, 2-13  
equipment required for verification, 4-4  
equipment requirements, 2-1  
erasing DLP, 1-2  
error messages, 5-1  
example programs, 6-67  
excess noise ratio, ENR, 2-12  
EXIT DLP, 3-11  
Ext Losses, 3-11

## F

failure, verification, 4-9  
features, vii  
frequency conversion, 3-12  
frequency converter measurements, 2-21  
frequency converting devices, 2-3  
FREQ VALUE, 3-12

## G

gain measurements, 2-17  
general safety considerations, vi

## H

HIGHEST PEAK, 3-12

## I

IF STOP FREQ, 3-12  
IF STRT FREQ, 3-12  
INPUT LOSS, 3-12  
installation, DLP, 1-2

INT AMP control, 3-12  
interpreting verification results, 4-7

## L

LAST POINT, 3-12  
limit lines, 2-27  
Limit Lines, 3-12  
loading DLP, 1-2  
LOG dB/DIV, 3-12  
losses, external, 2-6

## M

markers  
    delta, 2-25  
    display, 2-25  
MARKER TEMP, 3-12  
MEASURE ENR, 3-12  
measurement  
    bandwidth, 2-5  
    calibration, 2-15  
    configuration, 2-3  
measurement accuracy, 2-2  
    improving, 2-2  
measurement features, vii  
measurement personality messages, 5-1  
measurement points, number of, 2-4  
MEASURE NF, 3-12  
MEASURE NF and GAIN, 3-13  
measuring amplifier output ENR, 2-19  
menu pages, 3-1  
MINIMUM POINT, 3-13  
MKR NRM control, 3-13  
MKR TRA A B C, 3-13  
MORE 1 of 2, 3-13  
MORE 2 of 2, 3-13  
MSI IntCard, 3-13  
multiband frequency converter  
    measurements, 2-23

## N

NEXT POINT, 3-13  
noise figure measurements, 2-17  
noise source model number, 1-1

## O

operating messages, 5-1  
OUTPUT LOSS, 3-13

## P

parameters, time-bandwidth, 2-5  
performance verification, 4-4  
PlotPts control, 3-13  
PM MSIB COL, 3-13  
POINTS, 3-14  
power meter calibration, 4-5

preamp, internal, 2-11  
preamplifier model number, 1-1  
PREV MENU, 3-14  
printing, 2-30  
program examples, 6-67  
programming commands, 6-1

## R

recall, 3-14  
RECALL ENR, 3-14  
recalling ENR data, 2-13  
RECALL LIMIT, 3-14  
recommended noise source, 1-1  
recommended preamplifier, 1-1  
REF LVL, 3-14  
REF LVL POSN, 3-14  
requirements, equipment, 2-1  
RES BW, 3-14  
RF STOP FREQ, 3-14  
RF STRT FREQ, 3-14  
RL, 3-14

## S

safety, vi  
safety symbols, vi  
save, 3-14  
SAVE ENR, 3-15  
SAVE LIMIT, 3-15  
saving ENR data, 2-13  
service, returning your instrument, 5-6  
software product license agreement, iii-5  
SOURCE LOSS, 3-15  
SOURCE TEMP, 3-15  
specifications, 4-2  
spectrum analyzer calibration, 4-5  
START FREQ, 3-15  
START TEST, 3-15  
STOP FREQ, 3-15  
SWEEP ContSgl, 3-15  
syntax, command, 6-11  
system  
    characteristics, 4-2  
    specifications, 4-2  
    verification, 4-4

## T

T\*BW PRODUCT, 3-15  
temperature, entering, 2-11  
TEST POINTS, 3-15  
time-bandwidth parameters, 2-5  
time-bandwidth product, 2-6  
troubleshooting, 5-1  
TYPE, 3-15



**U**

UPPER/LOWER, 3-16

**V**

verification failure, 4-9

verification results, interpreting, 4-7

verification, system, 4-4

Verify Specs, 3-16

**W**

warning

    warning symbol, vi

warranty, v

